

## WARNING

Servicing a vehicle can be dangerous. If you have not received service-related training, the risks of injury and property damage increase. The recommended servicing procedures for the vehicle in this workshop manual were developed with Mazda-trained technicians in mind. This manual may be useful to non-Mazda trained technicians, but a technician with our service-related training and experience will be at less risk when performing servicing operations. However, all users of this manual are expected to know general safety procedures.

This manual contains "Warnings" and "Cautions" applicable to risks not normally encountered in a general technician's experience. They should be followed to reduce the risk of injury and the risk that improper service or repair may damage the vehicle or render it unsafe. It is also important to understand that the "Warnings" and "Cautions" are not exhaustive. It is impossible to warn of all the hazardous consequences that might result from failure to follow the procedures.

The procedures recommended and described in this manual are effective methods of performing service and repair. Some require tools specifically designed for a specific purpose. Non-

recommended procedures and tools should include consideration for safety of the technician and continued safe operation of the vehicle.

Parts should be replaced with genuine Mazda replacement parts, not parts of lesser quality. Use of a nonrecommended replacement part should include consideration for safety of the technician and continued safe operation of the vehicle.

# Mazda MX-5 Workshop Manual Supplement

## FOREWORD

For proper repair and maintenance, a thorough familiarization with this manual is important, and it should always be kept in a handy place for quick and easy reference.

All the contents of this manual, including drawings and specifications, are the latest available at the time of printing. As modifications affecting repair or maintenance occur, relevant information supplementary to this volume will be made available at Mazda dealers. This manual should be kept up-to-date.

Mazda Motor Corporation reserves the right to alter the specifications and contents of this manual without obligation or advance notice.

All rights reserved. No part of this book may be reproduced or used in any form or by any means, electronic or mechanical—including photocopying and recording and the use of any kind of information storage and retrieval system—without permission in writing.

## WARRANTY

The manufacturer's warranty on Mazda vehicles and engines can be voided if improper service or repairs are performed by persons other than those at an Authorized Mazda Dealer.

**Mazda Motor Corporation  
HIROSHIMA, JAPAN**

## APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN), and related materials shown on the following page.

## CONTENTS

Title	Section	
General Information	G1	
Fuel and Emission Control Systems	B6	F1
	BP	F2
Front and Rear Axles	M	
Steering System	N	
Braking System	P	
Body	S	
Body Electrical System	T	
Technical Data	TD	
Special Tools	ST	

There are explanations given only for the sections marked with shadow (■).

© 1995 Mazda Motor Corporation  
PRINTED IN JAPAN, SEP. '95 ①  
1509-10-95I

## VEHICLE IDENTIFICATION NUMBERS (VIN)

JM7 NA18P20# 300001 —

JM7 NA18C20# 300001 —

## RELATED MATERIALS

MX-5 Training Manual .....	3165-10-89I
MX-5 Workshop Manual .....	1221-10-89I
MX-5 Workshop Manual Supplement .....	1246-10-90G
MX-5 Workshop Manual Supplement .....	1372-10-93I
MX-5 Workshop Manual Supplement .....	1451-10-94L
323,626 / MX-6, XEDOS 6, XEDOS 9	
IMMOBILIZER SYSTEM SERVICE MANUAL .....	1503-10-95A
MX-5 Wiring Diagram (Europe) .....	5333-10-94L
MX-5 Wiring Diagram (UK) .....	5334-10-94L
MX-5 Wiring Diagram (Europe) .....	5360-10-95I
MX-5 Wiring Diagram (UK) .....	5361-10-95I

# GENERAL INFORMATION

**ABBREVIATIONS** ..... GI- 2  
**SCHEDULED MAINTENANCE** ..... GI- 2  
**SCHEDULED MAINTENANCE TABLE** .... GI- 2

### ABBREVIATIONS

ACC .....	Accessory	MT .....	Manual transmission
ATF .....	Automatic transmission fluid	RH .....	Right hand
IG .....	ignition	SST .....	Special service tool
LH .....	Left hand	SW .....	Switch
LSD .....	Limited slip differential		

### SCHEDULED MAINTENANCE

#### SCHEDULED MAINTENANCE TABLE

##### Chart symbols:

I: Inspect

~~Visual examination and/or functional measurement of a system's operating performance~~

~~A: Adjust~~

~~R: Replace~~

~~T: Tighten~~

##### Remarks:

- ~~To ensure efficient operation of the engine and all systems related to emission control, the ignition and fuel systems must be serviced regularly. It is strongly recommended that all servicing related to these systems be done by an authorized Mazda Dealer.~~
- After 90,000 km {54,000 miles} or 72 months, continue to follow the described maintenance at the recommended intervals.
- Refer below for a description of items marked\* in the maintenance chart.
  - \*1 : Also adjust and inspect the power steering and air conditioner drive belts, if equipped.
  - \*2 : Replacement of the timing belt is required at every 90,000 km {54,000 miles}. Failure to replace the timing belt may result in damage to the engine.
  - \*3 : If the vehicle is operated under any of the following conditions, change the engine oil and oil filter every 10,000 km {6,000 miles} or shorter.
    - a) Driving in dusty conditions
    - b) Extended periods of idling or low speed operation
    - c) Driving for long periods in cold temperatures or driving regularly at short distances ( less than 8 km {5 miles}) only
  - \*4 : If the vehicle is operated in very dusty or sandy areas, inspect and replace, if necessary the air cleaner element more often than the recommended intervals.
  - \*5 : This is a full function check of electrical systems such as lights, wiper and washer systems (including wiper blades), and power windows.
  - \*6 : If the brakes are used extensively (for example, continuous hard driving or mountain driving) or if the vehicle is operated in extremely humid climates, change the brake fluid annually.

# SCHEDULED MAINTENANCE

**GI**

Maintenance interval	Number of months or kilometers (miles), whichever comes first							
	Months	—	12	24	36	48	60	72
	Kilometers	1,000	15,000	30,000	45,000	60,000	75,000	90,000
Maintenance item	Miles	600	9,000	13,000	27,000	36,000	45,000	54,000
Drive belts*		A	I	I	I	I	II	II
Engine timing belt* <sup>2</sup>	Replace every 90,000 km {54,000 miles}							
Engine oil* <sup>3</sup>			R	R	R	R	R	R
Oil filter* <sup>3</sup>			R	R	R	R	R	R
Cooling system (including coolant level adjustment)				I		I		I
Engine coolant	Replace every 2 years							
Idle speed				A		A		A
Air cleaner element* <sup>4</sup>			I	I	R	I	I	R
Fuel filter						R		
Fuel lines and hoses				I		I		I
Initial ignition timing				I		I		I
Spark plugs				A		A		A
Spark plugs (only for sweden)	Adjust every 50,000 km {30,000 miles}							
EGR system				I		I		I
EGR system (only for sweden)	Inspect every 80,000 km {48,000 miles}							
Evaporative system				I		I		I
Evaporative system (only for sweden)	Inspect every 80,000 km {48,000 miles}							
Dash pot				A		A		A
Dash pot (only for sweden)	Adjust every 80,000 km {48,000 miles}							
Battery condition	I	I	I	I	I	I	I	I
All electrical system* <sup>5</sup>			I	I	I	I	I	I
Headlight alignment				A		A		A
Brake and clutch pedal			I	I	I	I	I	I
Clutch fluid			I	I	I	I	I	I
Brake lines, hoses and connections			I	I	I	I	I	I
Brake fluid* <sup>6</sup>			I	R	I	R	I	R
Parking brake		A	A	A	A	A	A	A
Power brake unit and hoses		I	I	I	I	I	I	I
Disc brakes		I	I	I	I	I	I	I
Power steering fluid		I	I	I	I	I	I	I
Power steering system and hoses		I	I	I	I	I	I	I
Steering and front suspension		I	I	I	I	I	I	I
Manual transmission oil				A		A		R
Rear axle oil				A		A		R
Drive shaft dust boots				I		I		I
Bolts and nuts on chassis and body	T	T	T	T	T	T	T	T
Body condition (for rust, corrosion and perforation)	Inspect annually							
Exhaust system and heat shields	I		I		I		I	
Tires (including spare tire) with inflation pressure adjustment		I	I	I	I	I	I	I
Hinges and catches		A	A	A	A	A	A	A
Underside of vehicle		I	I	I	I	I	I	I
Seat belts			I		I		I	
Road test		I	I	I	I	I	I	I

**GI**

Before beginning any service procedure, refer to section T of the MX-5 Workshop Manual (1451-10-94L) for air bag system service warnings.

# FUEL AND EMISSION CONTROL SYSTEMS (B6)

## FEATURES

OUTLINE .....	F1- 2
SYSTEM WIRING DIAGRAM .....	F1- 2
CONTROL SYSTEM .....	F1- 3
OUTLINE .....	F1- 3


## SERVICE

<b>SUPPLEMENTAL SERVICE</b>	
INFORMATION .....	F1- 3
<b>CONTROL SYSTEM</b> .....	F1- 3
ENGINE CONTROL MODULE (ECM) REMOVAL / INSTALLATION .....	F1- 3
ENGINE CONTROL MODULE (ECM) INSPECTION .....	F1- 4
<b>ON-BOARD DIAGNOSTIC SYSTEM</b> .....	F1- 5
DIAGNOSTIC TROUBLE CODE NUMBER INSPECTION .....	F1- 5

OUTLINE

- The ECM has been modified according to the addition of the immobilizer system.
- No changes have been made to vehicles that are not equipped with the immobilizer system.

SYSTEM WIRING DIAGRAM



## CONTROL SYSTEM

### OUTLINE

- Immediately after the engine is started, the immobilizer judges if the ignition key is valid or not. When the key is valid, the ECM continues to run the engine. When the key is invalid, the immobilizer unit actuates the ECM to carry out the fuel cut-off and the ignition cut-off operations, and as a result, the engine stops in a few seconds. (Refer to IMMOBILIZER SYSTEM SERVICE MANUAL.)

## SUPPLEMENTAL SERVICE INFORMATION

The following changes and / or additions have been made since publication of the Mazda MX-5 Workshop Manual Supplement (1451-10-94L) and IMMOBILIZER SYSTEM SERVICE MANUAL (1503-10-95A).

### Engine control module (ECM)

- Removal / Installation procedure modified
- Inspection procedure modified

### On-board diagnostic system

- Inspection procedure modified

F1

## CONTROL SYSTEM

### ENGINE CONTROL MODULE (ECM) REMOVAL / INSTALLATION

#### Note

- The ECM equipped on a vehicle with the immobilizer system operates normally only when the correct ID number and cord word are input in it. (Refer to IMMOBILIZER SYSTEM SERVICE MANUAL.)
- The ECM with the ID number and cord word stored is only applicable to the vehicle that the ECM has originally been equipped.

1. Disconnect the negative battery cable.
2. Lift up the floor mat in front of the passenger's seat.
3. Remove the protector cover.

#### Note



- If the set bolt is used, refer to set bolt removal note and set bolt installation note.


4. Disconnect the ECM connector.
5. Remove the ECM.
6. Install in the reverse order of removal.

#### Tightening torque:

18—26 N·m {1.8—2.7 kgf·m , 14—19 ft·lbf }


7. Input the ID number and cord word, referring to "IMMOBILIZER SYSTEM SERVICE MANUAL".





### Set bolt removal note

- Using a chisel and a hammer, cut a groove on the head of the set bolt so that a screwdriver can be inserted.
- Loosen the set bolt by using an impact screwdriver or pliers.



### Set bolt installation note

- Install new set bolt and tighten it until the neck of the bolt is cut.

### Tightening torque:

18.6—25.5 N·m {1.90—2.60 kgf·m, 13.8—18.8 ft·lbf}

## ENGINE CONTROL MODULE (ECM) INSPECTION

### Terminal voltage (Reference)

- Terminal voltage list has been modified. (Inspection procedure and SSTs are not modified.)

2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B

Terminal	Signal	Connected to	Test condition	Voltage (V)	Possible malfunction
1Q	Communication (Immobilizer)	Immobilizer unit	Check signal by using oscilloscope. Refer to "IMMOBILIZER SYSTEM SERVICE MANUAL"	—	<ul style="list-style-type: none"> <li>• ECM*1</li> <li>• Immobilizer unit</li> </ul>
2F	SGT	Camshaft position sensor	Ignition switch ON	Approx. 0 V or 5 V	<ul style="list-style-type: none"> <li>• Camshaft position sensor</li> </ul>
			Idle	Approx. 2 V	

\*1: If the immobilizer unit functions normally, replace the ECM.

ON-BOARD DIAGNOSTIC SYSTEM

DIAGNOSTIC TROUBLE CODE NUMBER INSPECTION


Note




- The following diagnostic trouble code numbers have been added according to the adoption of the immobilizer system. Other code numbers remain unchanged.

Code No.	Indicator pattern	Diagnosed circuit
71		Immobilizer unit—ECM communication error
72		ID number unregistered
73		Code words do not match
74		ID numbers do not match
75		Code word / ID number writing and reading error
76		Code word unregistered


F1

Diagnostic trouble code No.71		Immobilizer unit—ECM communication error	
Symptom		Command transmission exceeded limit	
Possible cause		<ul style="list-style-type: none"> <li>Defect in immobilizer unit—ECM communication line</li> <li>Immobilizer unit malfunction</li> <li>ECM malfunction</li> </ul>	
STEP	INSPECTION	ACTION	
1	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Go to next step
		No	Carry out troubleshooting of other diagnostic trouble code No. if displayed
2	Check continuity of wiring harness between immobilizer unit and ECM, and visually check connectors. Is there open or short circuit in communication line between ECM terminal and immobilizer unit terminal A?	Yes	Repair or replace as necessary
		No	Go to next step
3	Erase diagnostic trouble code from memory and start engine. Does engine continue running normally?	Yes	Carry out troubleshooting of other diagnostic trouble code No. if displayed
		No	If code No.71 displayed again, inspect immobilizer system and replace immobilizer unit. Refer to IMMOBILIZER SYSTEM SERVICE MANUAL.
4	Erase diagnostic trouble code from memory and start engine. Does engine continue running normally?	Yes	Carry out troubleshooting of other diagnostic trouble code No. if displayed
		No	If code No.71 displayed again, replace immobilizer unit and replace ECM. Refer to IMMOBILIZER SYSTEM SERVICE MANUAL.

<b>Diagnostic trouble code No.72</b>	<b>ID number unregistered</b>		
<b>Symptom</b>	ID number is not stored in ECM		
<b>Possible cause</b>	ECM replacement procedure not correct		
<b>STEP</b>	<b>ACTION</b>		
1	Reinput ID number	 <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>	

<b>Diagnostic trouble code No.73</b>	<b>Code words do not match</b>		
<b>Symptom</b>	Code words stored in immobilizer unit and ECM do not match		
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>• Transformation of code word stored in immobilizer unit</li> <li>• Transformation of code word stored in ECM</li> </ul>		
<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Go to next step
		No	Carry out troubleshooting of other diagnostic trouble code No. if displayed
2	Is diagnostic trouble code No.75 also shown?	Yes	Carry out troubleshooting of diagnostic trouble code No.75
		No	Go to next step
3	Using new key, carry out key duplication  <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b> Is code word (required for key duplication) entered?	Yes	Replace ECM  <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>
		No	Replace immobilizer unit  <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>

Do not use ECM on other vehicle for testing. Diagnostic trouble code No.73 will be displayed again.

<b>Diagnostic trouble code No.74</b>	<b>ID numbers do not match</b>		
<b>Symptom</b>	ID numbers stores in immobilizer unit and ECM do not match (Symptom occurs only after immobilizer unit is replaced and key ID number is registered)		
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>• Unregistered key is used</li> <li>• Transformation of ID number stored in ECM</li> </ul>		
<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Go to next step
		No	Carry out troubleshooting of other diagnostic trouble code No. if displayed
2	Start engine using another registered key. Does engine start normally?	Yes	Previous key defective of unregistered
		No	Replace immobilizer unit and ECM at same time using set parts  <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>

## ON-BOARD DIAGNOSTIC SYSTEM

# F1

<b>Diagnostic trouble code No.75</b>	<b>Code word / ID number writing and reading error</b>		
<b>Symptom</b>	ECM internal EEPROM damaged		
<b>Possible cause</b>	ECM internal EEPROM damaged		
<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>	
1	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM ☞ <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>
		No	Carry out troubleshooting of other diagnostic trouble code No. if displayed

<b>Diagnostic trouble code No.76</b>	<b>Code word unregistered</b>		
<b>Symptom</b>	Code word is not stored in ECM		
<b>Possible cause</b>	ECM replacement procedure not correct		
<b>STEP</b>	<b>ACTION</b>		
1	Reinput ID number	☞ <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>	

F1

Before beginning any service procedure, refer to section T of the MX-5 Workshop Manual (1451-10-94L) for air bag system service warnings.

## FUEL AND EMISSION CONTROL SYSTEMS (BP)

### FEATURES

OUTLINE .....	F2- 2
SYSTEM WIRING DIAGRAM .....	F2- 3
CONTROL SYSTEM .....	F2- 4
OUTLINE .....	F2- 4

F2

### SERVICE

SUPPLEMENTAL SERVICE INFORMATION .....	F2- 4
CONTROL SYSTEM .....	F2- 5
ENGINE CONTROL MODULE (ECM) REMOVAL / INSTALLATION .....	F2- 5
ENGINE CONTROL MODULE (ECM) INSPECTION .....	F2- 6
ON-BOARD DIAGNOSTIC SYSTEM .....	F2-11
DIAGNOSTIC TROUBLE CODE NUMBER INSPECTION .....	F2-11

**OUTLINE**


The following points have been changed compared with the previous model.

- Immobilizer system added.
- STA (start) signal eliminated.
- Following points modified according to the ECM modification.
  - ECM pin location modified.
  - Diagnostic trouble codes indicated in four digits.
  - Oxygen monitor function and switch monitor function eliminated. \*

\* By using the New Generation Star (NGS) tester, "PID/DATA MONITOR AND RECORD" function and "SIMULATION TEST" function become available instead of oxygen monitor function and switch monitor function.

Until the NGS tester is introduced, inspect the oxygen sensor and the switch system input signals by checking the ECM terminal voltages.

SYSTEM WIRING DIAGRAM



F2

**CONTROL SYSTEM****OUTLINE**

- Immediately after the engine is started, the immobilizer judges if the ignition key is valid or not. When the key is valid, the ECM continues to run the engine. When the key is invalid, the immobilizer unit actuates the ECM to carry out the fuel cut-off and the ignition cut-off operations, and as a result, the engine stops in a few seconds. (Refer to IMMOBILIZER SYSTEM SERVICE MANUAL.)

**SUPPLEMENTAL SERVICE INFORMATION**

The following changes and / or additions have been made since publication of the Mazda MX-5 Workshop Manual Supplement (1451-10-94L) and IMMOBILIZER SYSTEM SERVICE MANUAL (1503-10-95A).

**Engine control module (ECM)**

- Removal / Installation procedure modified
- Inspection procedure modified

**On-board diagnostic system**

- Inspection procedure modified

## CONTROL SYSTEM

## ENGINE CONTROL MODULE (ECM) REMOVAL / INSTALLATION

**Note**

- The ECM equipped on a vehicle with the immobilizer system operates normally only when the correct ID number and cord word are input in it. (Refer to IMMOBILIZER SYSTEM SERVICE MANUAL.)
- The ECM with the ID number and cord word stored is only applicable to the vehicle that the ECM has originally been equipped.

1. Disconnect the negative battery cable.
2. Lift up the floor mat in front of the passenger's seat.
3. Remove the protector cover.

**Note**

- If the set bolt is used, refer to set bolt removal note and set bolt installation note.

4. Disconnect the ECM connector.
5. Remove the ECM.
6. Install in the reverse order of removal.

**Tightening torque:**

18—26 N·m {1.8—2.7 kgf·m , 14—19 ft·lbf }

7. Input the ID number and cord word, referring to "IMMOBILIZER SYSTEM SERVICE MANUAL".

**Set bolt removal note**





- Using a chisel and a hammer, cut a groove on the head of the set bolt so that a screwdriver can be inserted.
- Loosen the set bolt by using an impact screwdriver or pliers.




**Set bolt installation note**

- Install new set bolt and tighten it until the neck of the bolt is cut.

**Tightening torque:**

18.6—25.5 N·m {1.90—2.60 kgf·m , 13.8—18.8 ft·lbf }





**ENGINE CONTROL MODULE (ECM) INSPECTION**

**Caution**

- The ECM terminal voltages vary with change in measuring conditions and vehicle conditions. Always carry out a total inspection of the input systems, output systems, and ECM to determine the cause of trouble. Otherwise, a wrong diagnosis will be made.

1. Disconnect the negative battery cable.
2. Remove the ECM.
3. Disconnect the ECM connector.
4. Connect the **SST** (Harness Adapter) to the ECM connector.
5. Connect the **SSTs** (Engine Signal Monitor and Harness adapter, power) to the **SST** (Harness Adapter). Use connector A of the harness adapter for ECM terminals 1A through 1V and 3A through 3P. Use connector B for ECM terminals 4A through 4Z.
6. Place the **SST** (Sheet) on the **SST** (Engine Signal Monitor).
7. Measure the voltage at each ECM terminal by switching the selector switch and the monitor switch.
8. If any incorrect voltage is detected, check related systems, wiring harnesses and connectors referring to the possible malfunction in the terminal voltage list.

**Caution**

- Disconnecting the connectors of the ECM and the **SST** (Harness Adapter) while the battery is connected can damage the ECM and the **SST** (Engine Signal Monitor). Disconnect the negative battery cable and the **SST** (harness adapter, power) before disconnecting the connectors.
- Applying voltage to terminals A and B of the **SST** (Engine Signal Monitor) can damage the **SST** (Engine Signal Monitor).

**Note**


- The indicator lights of the **SST** (Engine Signal Monitor), provided for confirmation of the voltmeter range, is also used for detection of the pulse such as the fuel injector control signal, which is difficult to detect by using the voltmeter.
- Terminals A and B of the **SST** (Engine Signal Monitor) are for connection of an external instrument. By connecting an external instrument such as a circuit tester or an oscilloscope, various inspections in addition to the measurement of the ECM terminal voltages are made possible.
- If the tires are rotated by using a chassis roller with the ignition switch at ON, the ABS control module may

ize the action as a malfunction and the ABS light may illuminate. If the ignition switch is to LOCK and then to ON again, the ABS warning light will not illuminate, because the action will be considered a past malfunction.

memori warning turned t light wil sidered

## Terminal voltage (Reference)

B+: Battery positive voltage  
\*1: In data link connector



Terminal	Signal	Connected to	Test condition		Voltage (V)	Possible malfunction
1A	Cooling fan control	Cooling fan relay	Ignition switch ON	Cooling fan operating/Terminal TEN ground and throttle valve open	Below 1.0	• Cooling fan relay
				Cooling fan stop	B+	
1B	Condenser fan control	Condenser fan relay	Ignition switch ON	Condenser fan operating/Terminal TEN ground and throttle valve open	Below 1.0	• Condenser fan relay
				Condenser fan stop	B+	
1C	—	—	—		—	—
1D	Serial communication	Data link connector terminal MEN or KLN *1	Carry out inspection according to diagnostic trouble code Diagnostic trouble code output is a part of serial communication Judgement by terminal voltage is not possible		—	• On-board diagnostic system
1E	Diagnostic trouble code output	Data link connector (Terminal FEN *1)	Ignition switch ON (Terminal TEN *1 grounded)	No diagnostic trouble code output	B+	• ECM terminal 1E —*1 FEN harness
				Diagnostic trouble code output	Below 1.0—B+	
1F	—	—	—		—	—
1G	A/C control	A/C relay	Ignition switch ON		B+	• A/C relay
			Idle	A/C operating	Below 2.0	
				A/C stop	B+	
1H	Headlight	Headlight switch	Headlight switch OFF		Below 1.0	• Headlight switch
			Headlight switch ON		B+	
1I	Diagnostic test mode	Data link connector (Terminal TEN *1)	Ignition switch ON	Open terminal *1TEN	B+	• ECM terminal 1I —*1TEN harness
				Short terminal *1TEN	Below 1.0	
1J	Rear window defroster	Rear window defroster relay	Ignition switch ON	Rear window defroster switch OFF	Below 1.0	• Rear window defroster relay
				Rear window defroster switch ON	B+	
1K	A/C	A/C switch	Idle	A/C switch and fan switch ON	Approx. 2.0	• A/C switch • Refrigerant pressure switch
				A/C switch OFF	B+	

B+: Battery positive voltage  
\*1: In data link connector

Terminal	Signal	Connected to	Test condition		Voltage (V)	Possible malfunction
1L	Load/No load distinction	Neutral/clutch switch	Ignition switch ON	Other than neutral position and clutch pedal released	B+	<ul style="list-style-type: none"> <li>• Neutral switch</li> <li>• Clutch switch</li> </ul>
				Neutral position or clutch pedal depressed	Below 1.0	
1M	Vehicle speed	Vehicle speed sensor	Ignition switch ON		Approx. 7.0 or Below 1.5	<ul style="list-style-type: none"> <li>• Vehicle speed sensor</li> </ul>
			Driving		Approx. 3.0	
1N	—	—	—		—	—
1O	—	—	—		—	—
1P	Blower	Fan switch	Ignition switch ON	Fan switch OFF or ON at 1st	B+	<ul style="list-style-type: none"> <li>• Fan switch</li> </ul>
				Fan switch ON at 2nd or higher	Below 1.0	
1Q	Brake	Brake switch	Brake pedal released		Below 1.0	<ul style="list-style-type: none"> <li>• Brake switch</li> </ul>
			Brake pedal depressed		B+	
1R	—	—	—		—	—
1S	Communication (Immobilizer)	Immobilizer unit	Check signal by using oscilloscope. Refer to "IMMOBILIZER SYSTEM SERVICE MANUAL"		—	<ul style="list-style-type: none"> <li>• ECM</li> <li>• Immobilizer</li> </ul>
1T	—	—	—		—	—
1U	Fuel pump control	Fuel pump relay	Ignition switch ON		B+	<ul style="list-style-type: none"> <li>• Fuel pump relay</li> </ul>
			Cranking		Below 1.0	
			Idle			
1V	Fuel pump control (Equipped with immobilizer)	Fuel pump relay	Ignition switch ON		B+	<ul style="list-style-type: none"> <li>• Fuel pump relay</li> </ul>
			Cranking		Below 1.0	
			Idle			
3A	—	—	—		—	—
3B	Mass air flow sensor (VGP)	Mass air flow sensor	Ignition switch ON		Below 1.0	<ul style="list-style-type: none"> <li>• Mass air flow sensor</li> </ul>
			Idle		1.0—2.0	
3C	Heated oxygen sensor	Heated oxygen sensor	Ignition switch ON		Approx. 0	<ul style="list-style-type: none"> <li>• Heated oxygen sensor</li> </ul>
			Idle	Engine cold	0.1—0.9	
				After warms up		
			Acceleration	0.5—1.0		
			Deceleration	0—0.5		
3D	—	—	—		—	—
3E	—	—	—		—	—

# CONTROL SYSTEM

# F2

B+: Battery positive voltage  
\*1: In data link connector





Terminal	Signal	Connected to	Test condition		Voltage (V)	Possible malfunction
3F	Throttle position (TVO)	Throttle position sensor	Ignition switch ON	Closed throttle position	0.1—1.1	<ul style="list-style-type: none"> <li>• Throttle position sensor</li> <li>• ECM terminal 3I voltage</li> </ul>
				Wide open throttle	3.1—4.5	
3G	Engine coolant temperature	Engine coolant temperature sensor	Ignition switch ON	Engine coolant temp. 20 °C {68 °F }	Approx. 2.5	<ul style="list-style-type: none"> <li>• Engine coolant temperature sensor</li> </ul>
				After warm up	Below 1.0	
3H	—	—	—		—	—
3I	Constant voltage (Vref)	Throttle position sensor EGR valve position sensor	Ignition switch ON		Approx. 5.0	<ul style="list-style-type: none"> <li>• ECM terminal 4B voltage</li> </ul>
3J	EGR valve position	EGR valve position sensor	Ignition switch ON		Approx. 0.8	<ul style="list-style-type: none"> <li>• EGR valve position sensor</li> <li>• ECM terminal 3I voltage</li> </ul>
			Idle			
3K	Intake air temperature	Intake air temperature sensor	Ignition switch ON	Intake air temperature 20 °C {68 °F }	Approx. 2.5	<ul style="list-style-type: none"> <li>• Mass air flow sensor</li> </ul>
3L	Closed throttle position	Closed throttle position switch	Ignition switch ON	Accelerator pedal released	Below 1.0	<ul style="list-style-type: none"> <li>• Throttle position sensor</li> </ul>
				Accelerator pedal depressed	B+	
3M	—	—	—		—	—
3N	—	—	—		—	—
3O	Analogue sensor ground	Ground	Constant		Below 1.0	<ul style="list-style-type: none"> <li>• ECM 3O terminal harness (Open)</li> </ul>
3P	Power steering pressure	Power steering pressure switch	Ignition switch ON		B+	<ul style="list-style-type: none"> <li>• Power steering pressure switch</li> </ul>
			Idle	P/S not operating		
				P/S operating	Below 1.0	
4A	ECM ground	Ground	Constant		Below 1.0	<ul style="list-style-type: none"> <li>• ECM 4A harness (Open)</li> </ul>
4B	Power supply	Main relay (FUEL INJ relay)	Ignition switch	OFF	Below 1.0	<ul style="list-style-type: none"> <li>• Main relay</li> </ul>
				ON	B+	
4C	Fuel injector ground	Ground	Constant		Below 1.0	<ul style="list-style-type: none"> <li>• ECM 4C terminal harness continuity (Open)</li> </ul>
4D	Output device ground	Ground	Constant		Below 1.0	<ul style="list-style-type: none"> <li>• ECM 4D terminal harness continuity (Open)</li> </ul>
4E	—	—	—		—	—

F2

B+: Battery positive voltage  
\*1: In data link connector

Terminal	Signal	Connected to	Test condition	Voltage (V)	Possible malfunction
4F	SGT	Camshaft position sensor	Ignition switch ON	0 or Approx. 5.0	• Camshaft position sensor
			Idle	Approx. 2.0	
4G	SGC		Ignition switch ON	0 or Approx. 5.0	
			Idle	Approx. 1.5	
4H	—	—	—	—	—
4I	Back-up power supply	Battery	Constant	B+	• ECM terminal 4I—battery harness and connector
4J	Pressure regulator control	PRC solenoid valve	Idle (Approx. 149 sec after hot start)	Below 3.0	• PRC solenoid valve
			Other	B+	
4K	—	—	—	—	—
4L	Engine speed	Tachometer	Ignition switch ON	0 or Approx. 11	• ECM terminal 4L—tachometer • ECM
			Idle	Approx. 6*	
4M	—	—	—	—	—
4N	IGT1	Ignition coil	Ignition switch ON	Below 1.0	• Ignition coil
			Idle	Approx. 0.2	
4O	EGR control (Vent)	EGR solenoid valve (Vent)	Ignition switch ON	B+	• EGR solenoid valve (Vent)
			Idle		
4P	EGR control (Vacuum)	EGR solenoid valve (Vacuum)	Ignition switch ON	B+	• EGR solenoid valve (Vacuum)
			Idle		
4Q	Idle air control	Idle air control	Ignition switch ON	Below 4.8	• Idle air control
			After warm up (NG)	Below 1.0	
4R	IGT2	Ignition coil	Ignition switch ON	Approx. 0.2	• Ignition coil
			Idle		
4S	—	—	—	—	—
4T	Purge control	Purge solenoid valve	Ignition switch ON	B+	• Purge solenoid valve
Idle					
4U	Fuel injector control	Fuel injector control	Fuel injector No.1	B+	• Fuel injector
4V			Fuel injector No.2		
4W			Fuel injector No.3		
4X			Fuel injector No.4		
4Y	—	—	—	—	—
4Z	—	—	—	—	—

\* Engine Signal Monitor: Green and red lights flash



## ON-BOARD DIAGNOSTIC SYSTEM

### DIAGNOSTIC TROUBLE CODE NUMBER INSPECTION Using the SST

1. Connect the **SST** (System Selector) to the data link connector.
2. Set system select to position 1.
3. Set test switch to SELF-TEST.
4. Connect the **SST** (Self-Diagnosis Checker) to the system selector connector and to a ground.
5. Set select switch to position A.
6. Turn the ignition switch to ON and verify that "88" flashes on the digital display and buzzer sounds for 3 seconds.
7. If not, check the main relay, power supply circuit, and data link connector wiring.
8. If "88" flashes and the buzzer sounds continuously for more than 20 seconds, check for a short circuit between ECM terminal 1E and the data link connector. Replace the ECM if necessary and perform step 3 through 7 again.
9. Note any code numbers and check for the causes by referring to the check sequences shown on page F2-12. Repair as necessary.


#### Note

- A diagnostic trouble code is consist of four numbers. They are shown one by one in the right window on the display by each flash. ("1" is always shown on the left window.)
- If there is no malfunction, "00" is displayed on the display.
- When there are multiple malfunctions, the codes are displayed in numerical order.

10. After repairs, cancel the code numbers by performing the "After Repair Procedure" (Refer to page F2-12).

#### Using a voltmeter

1. Connect the data link connector terminals TEN and GND by using a jumper wire.
2. Connect a voltmeter – (negative) terminal to the data link connector terminal FEN, and + (positive) terminal to the + (positive) terminal of the battery.
3. Turn the ignition switch to ON.
4. Observe the voltmeter needle and note the code number (s).











### After Repair Procedure

1. After repairs, disconnect the negative battery cable for at least 20 seconds, and depress the brake pedal. Reconnect the negative battery cable.
2. Warm up the engine to normal operating temperature.
3. Perform trouble code inspection again and verify that no service codes are displayed.

### Diagnostic trouble code

- For troubleshooting procedure of each diagnostic trouble code other than additional diagnostic trouble code, refer to the workshop manual for the previous model.

Code No.		Indicator pattern	Diagnosed circuit
Previous model	New model		
03	1345		Camshaft position sensor (SGC signal)
04	—	—	—
08	0100		Mass air flow sensor
09	0115		Engine coolant temperature sensor
10	0110		Intake air temperature sensor
12	0120		Throttle position sensor
14	1195		Barometric pressure sensor
15	0134		Heated oxygen sensor (inactivation)
16	1402		EGR valve position sensor
17	1170		Heated oxygen sensor (inversion)
25	1250		PRC solenoid valve
26	0443		Purge solenoid valve
28	1485		EGR solenoid valve (vacuum)
29	1486		EGR solenoid valve (vent)
34	0505		Idle air control valve

Code No.		Indicator pattern	Diagnosed circuit
Previous model	New model		
—	0500		Vehicle speed sensor
—	1602*		Immobilizer unit—ECM communication error (Immobilizer)
—	1603*		ID number unregistered (Immobilizer)
—	1604*		Code word unregistered (Immobilizer)
—	1608		ECM internal circuit malfunction
—	1621*		Code words do not match (Immobilizer)
—	1622*		ID numbers do not match (Immobilizer)
—	1623*		Code word / ID number writing and reading error (Immobilizer)

\* : Equipped with immobilizer

Diagnostic trouble code No. P0500		Vehicle speed sensor-malfunction	
<b>Symptom</b>		No vehicle speed sensor signal input from vehicle speed sensor while driving	
<b>Possible cause</b>		<ul style="list-style-type: none"> <li>• Vehicle speed sensor malfunction</li> <li>• Open or short circuit in wiring from vehicle speed sensor to ECM terminal 1M</li> </ul>	
STEP	INSPECTION	ACTION	
1	Does vehicle speed sensor connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 1M voltage OK?	Yes	Go to step 4
		No	Go to next step
3	Is there continuity between vehicle speed sensor terminal and PCM terminal 1M?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)

<b>Diagnostic trouble code No. P1602</b>		<b>Immobilizer unit—ECM communication error</b>	
<b>Symptom</b>		Command transmission exceeded limit	
<b>Possible cause</b>		<ul style="list-style-type: none"> <li>• Defect in immobilizer unit—ECM communication line</li> <li>• Immobilizer unit malfunction</li> <li>• ECM malfunction</li> </ul>	
<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Go to next step
		No	Carry out troubleshooting of other diagnostic trouble code No. if displayed
2	Check continuity of wiring harness between immobilizer unit and ECM, and visually check connectors. Is there open or short circuit in communication line between ECM terminal and immobilizer unit terminal A?	Yes	Repair or replace as necessary
		No	Go to next step
3	Erase diagnostic trouble code from memory and start engine. Does engine continue running normally?	Yes	Carry out troubleshooting of other diagnostic trouble code No. if displayed
		No	If code No. 1602 displayed again, inspect immobilizer unit Go to next step ☞ <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>
4	Erase diagnostic trouble code from memory and start engine. Does engine continue running normally?	Yes	Carry out troubleshooting of other diagnostic trouble code No. if displayed
		No	If code No. 1602 displayed again, replace immobilizer unit with previous one and replace ECM ☞ <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>

<b>Diagnostic trouble code No. P1603</b>		<b>ID number unregistered</b>	
<b>Symptom</b>		ID number is not stored in ECM	
<b>Possible cause</b>		ECM replacement procedure not correct	
<b>STEP</b>		<b>ACTION</b>	
1	Reinput ID number	☞ <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>	

<b>Diagnostic trouble code No. P1604</b>		<b>Code word unregistered</b>	
<b>Symptom</b>		Code word is not stored in ECM	
<b>Possible cause</b>		ECM replacement procedure not correct	
<b>STEP</b>		<b>ACTION</b>	
1	Reinput ID number	☞ <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>	

<b>Diagnostic trouble code No. 1608</b>		<b>ECM malfunction</b>	
<b>Symptom</b>		ECM does not read diagnostic trouble codes from output devices	
<b>Possible cause</b>		• ECM malfunction	
<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>	
—	—	Replace ECM	

## ON-BOARD DIAGNOSTIC SYSTEM

# F2

<b>Diagnostic trouble code No. P1621</b>	<b>Code words do not match</b>		
<b>Symptom</b>	Code words stored in immobilizer unit and ECM do not match		
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>• Transformation of code word stored in immobilizer unit</li> <li>• Transformation of code word stored in ECM</li> </ul>		
<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Go to next step
		No	Carry out troubleshooting of other diagnostic trouble code No. if displayed
2	Is diagnostic trouble code No.1623 also shown?	Yes	Carry out troubleshooting of diagnostic trouble code No. 1623
		No	Go to next step
3	Using new key, carry out key duplication ☞ <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b> Is code word (required for key duplication) entered?	Yes	Replace ECM ☞ <b>page F2-5</b>
		No	Replace immobilizer unit ☞ <b>IMMOBILIZER SYSTEM SERVICE MANUAL</b>

Do not use ECM on other vehicle for testing. Diagnostic trouble code No.1621 will be displayed again.

<b>Diagnostic trouble code No. P1622</b>	<b>ID numbers do not match</b>		
<b>Symptom</b>	ID numbers stored in immobilizer unit and ECM do not match (Symptom occurs only after immobilizer unit is replaced and key ID number is registered)		
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>• Unregistered key is used</li> <li>• Transformation of ID number stored in ECM</li> </ul>		
<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Go to next step
		No	Carry out troubleshooting of other diagnostic trouble code No. if displayed
2	Start engine using another registered key. Does engine start normally?	Yes	Previous key defective or unregistered
		No	Replace immobilizer unit and ECM at same time using set parts ☞ <b>page F2-5 and IMMOBILIZER SYSTEM SERVICE MANUAL</b>

<b>Diagnostic trouble code No. P1623</b>	<b>Code word / ID number writing and reading error</b>		
<b>Symptom</b>	ECM internal EEPROM damaged		
<b>Possible cause</b>	ECM internal EEPROM damaged		
<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM ☞ <b>page F2-5</b>
		No	Carry out troubleshooting of other diagnostic trouble code No. if displayed

Before beginning any service procedure, refer to section T of the MX-5 Workshop Manual (1451-10-94L) for air bag system service warnings.

## FRONT AND REAR AXLES

### FEATURES

OUTLINE .....	M- 2
OUTLINE OF CONSTRUCTION .....	M- 2
<b>TORQUE SENSING LIMITED SLIP</b>	
DIFFERENTIAL ("TORSEN" TYPE B LSD) .....	M- 2
OUTLINE .....	M- 2
CONSTRUCTION .....	M- 3
OPERATION .....	M- 4

# **M**OUTLINE, TORQUE SENSING LIMITED SLIP DIFFERENTIAL (“TORSEN” TYPE B LSD)

## **OUTLINE**

### **OUTLINE OF CONSTRUCTION**

- A torque sensing limited slip differential (“TORSEN” type B LSD) is an optional equipment for LH drive models to improve drivability and stability.

## **TORQUE SENSING LIMITED SLIP DIFFERENTIAL (“TORSEN” TYPE B LSD)**

### **OUTLINE**

- The “TORSEN” type B LSD has been equipped on the LH drive models, instead of the previous “TORSEN” type A LSD\*, to improve drivability and stability,
- The standard differential assembly and the “TORSEN” type B LSD assembly are interchangeable.
- The “TORSEN” type B LSD has the following benefits compared with the “TORSEN” type A LSD.

1. For operation restriction mechanism, the “TORSEN” type A LSD uses the friction of the worm gear teeth, while the “TORSEN” type B LSD employs the friction between the planet gear and the gear case, and between the side gear and the thrust washer.
2. In the “TORSEN” type A LSD, the bias ratio\*\* differs depending on the rotation direction. In the “TORSEN” type B LSD, however, the bias ratio is the same regardless of the rotation direction.

\* The differential which has been called “TORSEN” LSD in the previous manual is called “TORSEN” type A LSD in this manual.


#### **\*\* Bias ratio**

The bias ratio is to indicate the effectiveness of the LSD function. In the standard type differential, which applies the equal rotational torque to both RH and LH driving wheels, when either of the wheels is slipped by snow or ice and is spinning, the same amount of rotational torque is applied to the other wheel. In the LSD, rotational torque of the spinning wheel is increased and applied to the other wheel. This torque ratio is called bias ratio.

$$\text{Bias ratio} = \frac{\text{Rotational torque of slower wheel}}{\text{Rotational torque of faster wheel}}$$


# TORQUE SENSING LIMITED SLIP DIFFERENTIAL ("TORSEN" TYPE B LSD) **M**

## CONSTRUCTION



# M TORQUE SENSING LIMITED SLIP DIFFERENTIAL ("TORSEN" TYPE B LSD)

## OPERATION



\* The figure above shows the differential operation in the driving condition. When the engine brake is applied, all gears move in the opposite direction of the arrows and the side gears are pressed against the differential case.

### Limited-Slip Operation

When one of the driving wheels is spinning and the differential operation is restricted, thrust force and radial force are generated between the helical gears by engage reaction. Rotation torque of the spinning wheel is reduced by friction between the planet gear teeth and the gear case, between the planet gear end surface in axial direction and the gear case, and between the side gear and the thrust washer. The reduced torque is transmitted to the higher traction side, and functions as the limited-slip differential. This torque is proportional to the ring gear input torque.

# **TECHNICAL DATA**

**TECHNICAL DATA** ..... **TD- 2**  
M. FRONT AND REAR AXLES ..... **TD- 2**  
T. BODY ELECTRICAL SYSTEM ..... **TD- 2**

TECHNICAL DATA

M. FRONT AND REAR AXLES

Item	Engine/Transmission		BP DOHC
			MT
<b>Drive shaft</b>			
Joint type	Wheel side	Bell joint	
	Differential side	Double-offset joint	
Overall length (air in boot at atmospheric pressure mm { in })	Left side	767.3—777.3 {30.20—30.60}	
	Right side	767.3—777.3 {30.20—30.60}	
Shaft diameter	mm { in }	24.0 {0.94}	
<b>Differential</b>			
Differential type			"TORSEN" TYPE B LSD      Standard
Ring gear size	mm { in }	182.88 {7.20}	
Final gear ratio	4.100		
Reduction gear	Hypoid gear		
Differential gear	Helical gear		Straight-bevel gear
Ring gear teeth	41		
Drive pinion gear teeth	10		
Oil	Grade	API service GL-5	
	Viscosity	Above-18 °C {0 °F}: SAE90 Below-18 °C {0 °F}: SAE80	
	Capacity    L { US qt , Imp qt }	1.00 {1.06, 0.88}	

T. BODY ELECTRICAL SYSTEM

	Bulb	Specifications
Exterior light	Headlight	60/55W
	Front turn light	21W
	Front side turn light	5W
	Licence plate light	5W
	Rear turn light	21W
	Stop/taillight	21/5W
	Back-up light	21W
	High-mount brake light	18.4W
Interior light	Interior light	8W
Warning and indicator light	Generator warning light	1.4W
	Brake system warning light	1.4W
	Washer fluid-level warning light	1.4W
	ABS warning light	1.4W
	Air bag system warning light	1.4W
	Hazard warning light	1.4W
	Rear fog light indicator light	1.4W
	Retractor indicator light	1.4W
	Immobilizer indicator light	1.4W
	High beam indicator light	3.4W
	Rear window defroster indicator light	1.4W
	Turn signal indicator light	3.4W × 2
Instrument cluster illumination	3.4W × 4	

Before beginning any service procedure, refer to section T of the MX-5 Workshop Manual (1451-10-94L) for air bag system service warnings.

# STEERING SYSTEM

## FEATURES

OUTLINE .....	N- 2
OUTLINE OF CONSTRUCTION .....	N- 2

## SERVICE

SUPPLEMENTAL SERVICE	
INFORMATION .....	N- 2
MANUAL STEERING .....	N- 2
STEERING WHEEL AND COLUMN DISASSEMBLY / ASSEMBLY .....	N- 2

# N OUTLINE, SUPPLEMENTAL SERVICE INFORMATION, MANUAL STEERING

## OUTLINE

### OUTLINE OF CONSTRUCTION

- Due to the addition of the immobilizer system, when replacing the steering lock for the steering wheel and column, the ID code must be input into the system, because if this is not done, the engine can not be started.

## SUPPLEMENTAL SERVICE INFORMATION

The following changes and / or additions have been made since publication of the Mazda MX-5 Workshop Manual (1221-10-89I).

### Steering wheel and column

- Disassembly / Assembly procedures modified


## MANUAL STEERING

### STEERING WHEEL AND COLUMN DISASSEMBLY / ASSEMBLY

#### Caution

- After replacing the steering lock with a new one, the engine cannot be started without inputting the ID number of the keys. Input the ID number, referring to "key replacement or duplicate keys" (Refer to IMMOBILIZER SYSTEM General Information, section T.)

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Steering lock mounting bolts and bracket
2. Steering lock assembly
3. Steering shaft
4. Intermediate shaft

**Before beginning any service procedure, refer to section T of the MX-5 Workshop Manual (1451-10-94L) for air bag system service warnings.**

# BRAKING SYSTEM

## FEATURES

**OUTLINE** ..... P- 2  
**OUTLINE OF CONSTRUCTION** ..... P- 2

## SERVICE

**SUPPLEMENTAL SERVICE INFORMATION** ... P- 2  
**ANTILOCK BRAKE SYSTEM (ABS)** ..... P- 2  
    **ABS CONTROL MODULE**  
    **REMOVAL / INSTALLATION** ..... P- 2

**OUTLINE**

**OUTLINE OF CONSTRUCTION**

- For models with the immobilizer system, the bolts which fix the ABS control module panel have been changed. Set bolts are now used.

**SUPPLEMENTAL SERVICE INFORMATION**

The following changes and / or additions have been made since publication of the Mazda MX-5 Workshop Manual Supplement (1451-10-94L).

**ABS control module**

- Removal / Installation procedure modified


**ANTILOCK BRAKE SYSTEM (ABS)**

**ABS CONTROL MODULE REMOVAL / INSTALLATION**

1. Lift up the passenger side carpet.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.

**Caution**

- Connect the connector securely. If a poor contact occurs, the ABS may malfunction.



N·m { kgf·m , ft·lbf }

- |                            |                         |
|----------------------------|-------------------------|
| 1. Bolt and nut            | 4. Control module panel |
| 2. Nut                     | 5. Connector            |
| 3. Set bolt                | 6. ABS control module   |
| Refer to removal note      |                         |
| Refer to installation note |                         |

**Set Bolt Removal Note**

(Refer to Section F2.)

**Set Bolt Installation Note**

(Refer to Section F2.)

Before beginning any service procedure, refer to section T of the MX-5 Workshop Manual (1451-10-94L) for air bag system service warnings.

# BODY

## FEATURES

OUTLINE ..... S- 2  
OUTLINE OF CONSTRUCTION ..... S- 2

## SERVICE

SUPPLEMENTAL SERVICE INFORMATION . S- 2  
REARVIEW MIRROR ..... S- 2  
REARVIEW MIRROR REMOVAL /  
INSTALLATION ..... S- 2

# S OUTLINE, SUPPLEMENTAL SERVICE INFORMATION, REARVIEW MIRROR

## OUTLINE

### OUTLINE OF CONSTRUCTION

- The rearview mirror has been redesigned.

## SUPPLEMENTAL SERVICE INFORMATION

The following changes and / or additions have been made since publication of the Mazda MX-5 Workshop Manual Supplement (1221-10-89I).


### Rearview mirror

- Removal / Installation procedure modified

## REARVIEW MIRROR

### REARVIEW MIRROR REMOVAL / INSTALLATION

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Rearview mirror  
Rearview mirror  
removal note ..... page S-3

2. Base  
Base removal note ..... page S-3  
Base installation note ..... page S-3


# REARVIEW MIRROR

S




### Rearview Mirror Removal Note

1. Insert a flathead screwdriver between the mirror and the base.
2. Push the base pin to remove the mirror.




### Base Removal Note

1. Wind each end of a wire around a bar.
2. Saw through the sealant to remove the base using a sawing action to spread the work over the wire to prevent it from breaking.



### Base Installation Note

1. Cut away all of the original sealant by using a razor knife.
2. Clean and degrease the glass.
3. Apply primer to the glass and the base. Use body primer on the glass and body primer on the base. Clean the bonding area free of dirt and grease, and allow the surface to dry for approximately 30 minutes.
4. Apply a 3 mm {0.12 in} bead of repair sealant around the base.



5. Center the base in the ceramic coating and press it onto the glass. Use ethyl alcohol to remove any excess sealant.

### Hardening time of repair sealant

Temperature	Surface hardening time	Time required until car can be put into service
5 °C {41 °F}	Approx. 1.5 hr	
20 °C {68 °F}	Approx. 1 hr	
35 °C {95 °F}	Approx. 10 min	

Use a long hole length of

a razor knife.

Use only glass base. Keep do not touch approximately 30

t to the base.

S

press it onto excess repair

Required until car put into service

12 hr
4 hr
2 hr

Before beginning any service procedure, refer to section T of the MX-5 Workshop Manual (1451-10-94L) for air bag system service warnings.

## BODY ELECTRICAL SYSTEM

### FEATURES

OUTLINE .....	T- 2
OUTLINE OF CONSTRUCTION .....	T- 2
<b>IMMOBILIZER SYSTEM</b> .....	T- 2
OUTLINE .....	T- 2

### SERVICE

<b>SUPPLEMENTAL SERVICE</b>	
INFORMATION .....	T- 2
<b>POWER SYSTEM</b> .....	T- 2
IGNITION SWITCH INSPECTION .....	T- 2
<b>INTERIOR LIGHTING SYSTEM</b> .....	T- 3
INTERIOR LIGHT REMOVAL/ INSTALLATION .....	T- 3
<b>IMMOBILIZER SYSTEM</b> .....	T- 4
STRUCTURAL VIEW .....	T- 4
IMMOBILIZER UNIT REMOVAL/ INSTALLATION .....	T- 5

**OUTLINE**

**OUTLINE OF CONSTRUCTION**

- Immobilizer system has been added.

**IMMOBILIZER SYSTEM**

**OUTLINE**

The immobilizer system of the Mazda MX-5 is basically the same as that of the Mazda 626, 626i, MX-6, XEDOS 6, and XEDOS 9.

**SUPPLEMENTAL SERVICE INFORMATION**

The following changes and / or additions have been made since publication of the Mazda MX-5 Workshop Manual (1221-10-89I), Mazda MX-5 Workshop Manual Supplement (1246-10-90G), Mazda MX-5 Workshop Manual Supplement (1372-10-93I), and Mazda MX-5 Workshop Manual Supplement (1451-10-94L).

**Ignition switch**


- Inspection procedure added

**Interior light**

- Removal / Installation procedure modified

**Immobilizer unit**

- Removal / Installation procedure added



**POWER SYSTEM**

**IGNITION SWITCH INSPECTION**

**Vehicles equipped with immobilizer system**

1. Disconnect the ignition switch connector.
2. Check for continuity between the terminals of the switch

○—○ : Continuity

Terminal	C	D	F	B	A	E
Switch position						
LOCK						
ACC	○—○		○—○			
ON	○—○		○—○	○—○		
		○—○			○—○	
START	○—○			○—○		
		○—○				○—○


3. If not as specified, replace the steering lock.  
(Refer to section N, MANUAL STEERING, STEERING WHEEL AND COLUMN DISASSEMBLY/ASSEMBLY.)

**INTERIOR LIGHTING SYSTEM**

**INTERIOR LIGHT REMOVAL / INSTALLATION**

1. Insert a flathead screwdriver which has been wrapped in tape as shown in the figure.

2. Twist the screwdriver to remove the lens.




3. Remove the screw.

4. Disconnect the interior light connector.

5. Remove the housing.

6. Remove the bulb.

7. Install in the reverse order of removal.




## IMMOBILIZER SYSTEM

**Caution**

- When an immobilizer system component (such as the ECM (PCM), Immobilizer unit, coil and pre-amplifier, or the key) has failed, it must be accurately determined according to the troubleshooting procedures or by the display of the diagnostic trouble codes prior to carrying out the service procedures. If a normal component is mistakenly replaced and the ID number and / or code word are input into the new component, then neither component can be reused on other vehicles.

## STRUCTURAL VIEW



1. Coil
2. Pre-amplifier


3. Immobilizer unit

**Note**

- The coil and the pre-amplifier are part of the assembly with the steering lock. When the coil and/or pre-amplifier must be replaced, replace the steering lock. (Refer to section N, MANUAL STEERING, STEERING WHEEL AND COLUMN DISASSEMBLY / ASSEMBLY.)

**Note**

- The following service procedure for the Mazda MX-5 are basically the same as for the Mazda 323, 626, MX-6, XEDOS 6, and XEDOS 9.
  - Coil and pre-amplifier inspection
  - Immobilizer unit inspection
  - ID number input procedure
  - CODE WORD input procedure

**IMMOBILIZER UNIT REMOVAL / INSTALLATION**

1. Remove the center lower panel assembly.
2. Remove the nut.
3. Remove the bracket.
4. Disconnect the connector.
5. Remove the screws.
6. Remove the immobilizer unit.
7. Install in the reverse order of removal.

**Caution**

- After replacing the immobilizer unit with a new one, the engine cannot be started without inputting the ID number of the keys and the code word of the new immobilizer unit. Input the ID number and code word.

# **SPECIAL TOOLS**

**SPECIAL TOOLS** ..... **ST- 2**  
**GENERAL INFORMATION** ..... **ST- 2**  
**CHECKERS AND OTHER EQUIPMENT** . **ST- 2**

### SPECIAL TOOLS

#### GENERAL INFORMATION

The letters A and B in the priority column indicate the degree of importance of each tool.





A . . . . . indispensable



The tools ranked A in this list are indispensable for performing operations satisfactorily, easily, safely, and efficiently. It is therefore advisable that all service shops have these tools.

B . . . . . Selective

The tools ranked B in this list are not as necessary as tools ranked A, but all service shops should have them to perform repairs more easily and efficiently.

#### CHECKERS AND OTHER EQUIPMENT

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 9200 162A Engine signal monitor	A	
49 T018 902 Harness adapter	A	
49 H018 9A1 Self-Diagnosis checker	A	
49 F018 903 Sheet (BP)	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G018 906 Sheet (B6)	A	
49 D088 008 Harness adapter power	A	
49 B019 9A0 System selector	A	