

2007 Mazda MX-5 Bodyshop Manual

FOREWORD

This bodyshop manual is intended for use by technicians of Authorized Mazda Dealers to help them service and repair Mazda vehicles. It can also be useful to owners and operators of Mazda vehicles in performing limited repair and maintenance on Mazda vehicles.

For proper repair and maintenance, a thorough familiarization with this manual is important, and it should always be kept in a handy place for quick and easy reference.

All the contents of this manual, including drawings and specifications, are the latest available at the time of printing. As modifications affecting repair or maintenance occur, relevant information supplementary to this volume will be made available at Mazda dealers. This manual should be kept up-to-date.

Mazda Motor Corporation reserves the right to alter the specifications and contents of this manual without obligation or advance notice.

All rights reserved. No part of this book may be reproduced or used in any form or by any means, electronic or mechanical including photocopying and recording and the use of any kind of information storage and retrieval system-without permission in writing.

**Mazda Motor Corporation
HIROSHIMA, JAPAN**

CONTENTS

Title		Section
GENERAL INFORMATION		00
BODY STRUCTURE	CONSTRUCTION	80A
	PANEL REPLACEMENT	80B
	WATER-PROOF AND RUST PREVENTIVE	80C
	DIMENSIONS	80D
	PLASTIC BODY PARTS	80E

APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN), shown on the following page.

© 2006 Mazda Motor Corporation
PRINTED IN U.S.A., JUNE 2006
Form No. 3426-1U-06F
Part No. 9999-95-060F-07

VEHICLE IDENTIFICATION NUMBERS (VIN)

JM1	NC15F*7#	100001—
JM1	NC16F*7#	100001—
JM1	NC25F*7#	100001—
JM1	NC26F*7#	100001—

GENERAL INFORMATION

00
SECTION

00-00

GENERAL INFORMATION 00-00

00-00 GENERAL INFORMATION

VEHICLE IDENTIFICATION NUMBER	
(VIN) CODE	00-00-2
VEHICLE IDENTIFICATION NUMBER	
(VIN)	00-00-2
HOW TO USE THIS MANUAL	00-00-3
Efficient Replacement of	
Body Panels	00-00-3
Symbols of Panel Replacement	00-00-4
Body Dimensions	
(Flat-plane Dimensions)	00-00-4
Body Dimensions	
(Straight-line Dimensions)	00-00-6
Symbols of Body Dimensions	00-00-8
SERVICE PRECAUTIONS	00-00-8
Arrangement of Workshop	00-00-8
Safety Precautions	00-00-8
Vehicle Protection	00-00-8
Remove Dangerous Articles	00-00-9
Use of Pulling Equipment	00-00-9
Prevent Short Circuits	00-00-9
EFFICIENT REMOVAL OF BODY	
PANELS	00-00-10
Body Measurements	00-00-10
Prevention of Body Deformation	00-00-10

Selection of Cut-and-join	
Locations	00-00-10
Removal of Associated Parts	00-00-10
Rough Cutting of Damaged Panel	00-00-11
INSTALLATION PREPARATIONS	00-00-11
Rough Cutting of New Parts	00-00-11
Determination of Welding	
Method	00-00-11
Making Holes for CO ₂ Arc	
Welding	00-00-12
Application of Weld-through	
Primer	00-00-12
EFFICIENT INSTALLATION OF	
BODY PANELS	00-00-12
Checking Preweld Measurements And	
Watching	00-00-12
Welding Notes	00-00-13
Spot Welding Notes	00-00-13
Checking Weld Strength	00-00-14
ANTICORROSION, SOUND INSULATION, AND	
VIBRATION INSULATION	00-00-15
Body Sealing	00-00-15
Application of Undercoating	00-00-15
Application of Rust Inhibitor	00-00-15
Application of Damping Sheet	00-00-16
ABBREVIATION	00-00-16

GENERAL INFORMATION

VEHICLE IDENTIFICATION NUMBER (VIN) CODE

id000000100200

J	M	1	N	C	1	5	F	*	7	#	1	2	3	4	5	6
											Serial No.					
											Plant		0= Hiroshima 1= Hofu			
											Model year		7= 2007			
											Check digit		*= 0 to 9, X			
											Engine		F= 2.0 L (LF)			
											Body		5= 2-door Open, Convertible Top 6= 2-door Open, Power Retractable Hardtop			
											Restraint system		1= without Side air bag 2= with Side air bag			
											Carline, series		NC= Mazda MX-5			
											World manufacturer identification		JM1= Mazda/Passenger car			

amxuub0000001

VEHICLE IDENTIFICATION NUMBER (VIN)

id000000100300

JM1 NC15F*7# 100001—
JM1 NC16F*7# 100001—
JM1 NC25F*7# 100001—
JM1 NC26F*7# 100001—

GENERAL INFORMATION

HOW TO USE THIS MANUAL


id00000600900

00-00

Efficient Replacement of Body Panels

- This section contains information on the body panels in regard to the welding types, number of spot welds, and cut-and-join locations that are necessary for panel removal and installation.
- The type of weld and position are indicated by symbols.
- Some sections have notes concerning the operation being performed. Thoroughly read and understand the notes before carrying out any procedures.

Example



GENERAL INFORMATION

Symbols of Panel Replacement


- The following 6 symbols are used to indicate the type of weld that is used when replacing body panels.

SYMBOL	MEANING	SYMBOL	MEANING
●	Spot welding		Continuous MIG welding (Cut-and-join location)
■	CO ² arc welding (plug welding)	○○	Braze welding
+	CO ² spot welding	∩	Rough cut location

MZZ2010B002

Body Dimensions (Flat-plane Dimensions)

- Flat-plane dimensions are the dimensions measured by projecting certain reference points onto a plane surface.




DPE2010B010

GENERAL INFORMATION

- When there are no specific indications, the standard points and dimensions are symmetrical in regard to the center of the vehicle.
- The hypothetical lines may differ according to the vehicle model.
- The schematic diagram shows the vehicle as it is projected from the underbody.

Example




00-00

DPE2010B003

GENERAL INFORMATION

Body Dimensions (Straight-line Dimensions)

- Straight-line dimensions are the actual dimensions between two standard points.



DPE2010B011


GENERAL INFORMATION

- When there are no specific indications, the standard points and dimensions are symmetrical in regard to the center of the vehicle.

Example

00-00


ROOM STRAIGHT-LINE DIMENSIONS (1)



Shows details of the standard point location

Shows position and shape of the points

Shows point indication
Without apostrophe:RH
With apostrophe:LH



Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Front pillar inner designation	f16
B	Front pillar inner designation	f17
C	Harness installation hole	f31
D	Front floor pan designation	M14
E	Adjuster installation hole	f16

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
F	Trim installation hole	f18
G	Harness installation hole	f16
H	Chaker bracket installation hole	17 x 29.5
I	Chaker bracket installation hole	f12

Shows hole diameter

Shows slot








Shows bolt size

DPE2010B004

GENERAL INFORMATION

Symbols of Body Dimensions

- The following 8 symbols are used to indicate the standard points.

SYMBOL	MEANING	SYMBOL	MEANING
	Center of circular hole		Bolt tip
	Center elliptical hole		Center of rectangular-shaped hole
	Notch		Edge of rectangular-shaped hole
	Panel seam, bead, etc.		

MZZ2010B016

SERVICE PRECAUTIONS


id000000739200

Arrangement of Workshop

- Arrangement of the workshop is important for safe and efficient work.

Safety Precautions


- Protective head covering and safety shoes should always be worn. Depending upon the nature of the work, gloves, safety glasses, ear protectors, face shield, etc., should also be used.



MZZ2036B001

Vehicle Protection

- Use seat covers and floor covers.
- Use heat-resistant protective covers to protect glass areas and seats from heat or sparks during welding.
- Protect items such as moldings, garnishes, and ornaments with tape when welding.




MZZ2036B002

GENERAL INFORMATION

00-00

Remove Dangerous Articles


- Remove the fuel tank before using an open flame in that area. Plug connection piping to prevent fuel leakage.



MZZ2036B003

Use of Pulling Equipment

- When using pulling equipment, keep away from the pulling area and use safety wires to prevent accidents.




MZZ2036B004

Prevent Short Circuits


- Turn the ignition switch to the LOCK position.
- Disconnect the battery cables.

Note

- When connecting the negative battery cable to the battery, connect the negative battery cable and the ground cable as shown in the figure.




MZZ2036B005



E5U117ZW5004

GENERAL INFORMATION

- Securely connect the welding machine ground near the welding area.




MZZ2036B006

EFFICIENT REMOVAL OF BODY PANELS

id000000739300

Body Measurements


- Before removal or rough-cutting, first measure the body at and around the damaged area against the standard reference dimension specifications. If there is deformation, use frame repair equipment to make a rough correction.



MZJ2038B001

Prevention of Body Deformation


- Use a clamp or a jack for removal and reinforce at and around the rough-cutting location to prevent deforming of the body.



MZJ2038B002

Selection of Cut-and-join Locations

- For parts where complete replacement is not feasible, careful cutting and joining operations should be followed. If the location to be cut is a flat area where there is no reinforcement, the selected cutting location should be where the welding distortion will be minimal.



MZJ2038B003

Removal of Associated Parts


- Protect moldings, garnishes, and ornaments with tape when removing associated parts.

GENERAL INFORMATION

00-00

Rough Cutting of Damaged Panel

- Verify that there are no parts (such as pipes, hoses, and wiring harness) nearby or on the opposite side of a panel which could be damaged by heat.
- For cut-and-join areas, allow for an overlap of 30—50 mm {1.18—1.97 in} and then rough-cut the damaged panel.




MZZ2038B001

INSTALLATION PREPARATIONS

id000000739400

Rough Cutting of New Parts


- For cut-and-join areas, allow for an overlap of 30—50 mm {1.18—1.97 in} with the remaining area on the body side and then rough-cut the new parts.



MZZ2038B002

Determination of Welding Method

- If the total thickness at the area to be welded is 3 mm {0.12 in} or more, use a CO₂ gas shielded-arc welder to make the plug welds.



MZZ2038B003

GENERAL INFORMATION


Making Holes for CO₂ Arc Welding

- For places that cannot be spot welded, make a hole for CO₂ arc welding using a punch or drill as follows.

(mm {in})

Panel thickness (ø)	Hole diameter (ø)
0.60—0.90 {0.02—0.03}	5 {0.19}
0.91—1.20 {0.04—0.05}	6 {0.23}
1.21—1.80 {0.051—0.07}	8 {0.31}
1.81—4.50 {0.071—0.17}	10 {0.39}


- Grind the shaded section indicated in the diagram below and create a hole in the part where the 3—4 plates are put together. Also, weld the plates together tightly so that gaps do not develop.



MZZ2038B004

Application of Weld-through Primer

- For treatment against corrosion, remove the paint grease, and other material from the portion of new part and body to be welded, and apply weld-through primer.




MZJ2038B008

EFFICIENT INSTALLATION OF BODY PANELS

Checking Preweld Measurements And Watching

- Align to the standard reference dimensions, based upon the body dimensions illustration, so that new parts are installed in the correct position.




MZJ2038B009

GENERAL INFORMATION

00-00

Welding Notes


- For the number of weld points, welding should be performed in accordance with the following reference standards.



DPE2038B005


Spot Welding Notes

- The shape of the spot welder tip is $D=(2 \times t)+3$. If the upper panel thickness is different from that of the under panel, adjust to the thinner one.




MZZ2038B009

- Because the weld strength is affected by the shape of the spot welder tip, the optimum condition of the tip should always be maintained.
- Spot welds should be made at points other than the originally welded points.



MZJ2038B012

- Before spot welding, make a trial weld using the same material as the body panel to check the weld strength.




MZZ2038B006

GENERAL INFORMATION


Checking Weld Strength

- Installation locations of the engine, chassis, and seat belts are designated as important safety locations for weld strength. Check weld strength by driving a chisel between the panels at every fourth or fifth weld spot, and every tenth regular weld location.



MZZ2038B007

- Drive the chisel between the panels according to the number of panels as shown below.
- To determine weld strength, drive the chisel between the panel and check whether the panels come apart. If the panels come apart, make another weld near the original weld.
- Restore the shape of the checked area.



MZZ2038B008


GENERAL INFORMATION

ANTICORROSION, SOUND INSULATION, AND VIBRATION INSULATION

id000000739600

Body Sealing

- Apply body sealer where necessary.
- For locations where application of body sealer is difficult after installation, apply it before installation.




CJJ2038B016

00-00

Application of Undercoating


- Apply an undercoat to the required location of the body.



CJJ2038B017

Application of Rust Inhibitor

- Apply rust inhibitor (wax, oil, etc.) to the back of the welded areas.




CJJ2038B018

GENERAL INFORMATION

Application of Damping Sheet

- Apply damping sheet by heating with an infrared ray lamp.



CJJ2038B019

ABBREVIATION

id000000000800

CM	Control module
Ctr	Center
DSC	Dynamic stability control
Fr	Front
HU	Hydraulic unit
LH	Left
M	Metallic
MC	Mica
RH	Right
Rr	Rear

BODY & ACCESSORIES

09
SECTION

09-80A

BODY STRUCTURE
[CONSTRUCTION] 09-80A
BODY STRUCTURE[PANEL
REPLACEMENT] 09-80B
BODY STRUCTURE
[WATER-PROOF AND RUST
PREVENTIVE]..... 09-80C

BODY STRUCTURE
[DIMENSIONS] 09-80D
BODY STRUCTURE
[PLASTIC BODY PARTS] . . . 09-80E

09-80A BODY STRUCTURE [CONSTRUCTION]


BODY COMPONENTS CONSTRUCTION
[CONSTRUCTION]..... 09-80A-2
ADOPTION OF ULTRA HIGH-TENSION
STEEL[CONSTRUCTION]..... 09-80A-5

Characteristics of Ultra High-Tensile
Steel Plates 09-80A-5
Range of Use and
Cautions for Service..... 09-80A-5

BODY STRUCTURE [CONSTRUCTION]

BODY COMPONENTS CONSTRUCTION[CONSTRUCTION]

id098007739700



amxuub000000

BODY STRUCTURE [CONSTRUCTION]

x:Applied
-:Not applied

09-80A

No.	Part Name	Ultra high-tension steel	High-tension steel	Rust proof steel	Thickness (mm) {in}
1	Hood*	-	-	-	0.95 {0.037}
2	Shroud upper panel	-	-	x	0.70 {0.028}
3	Shroud lower panel	-	-	x	0.70 {0.028}
4	Front bumper bracket	-	x	-	2.00 {0.079}
5	Front side frame (outer)	x	-	x	1.00 {0.039}
6	Front side frame	x	-	x	1.60 {0.063}
7	Suspension housing	-	-	x	2.60 {0.102}
8	Apron reinforcement (upper)	-	x	x	0.90 {0.035}
9	Front fender panel	-	-	x	0.75 {0.030}
10	Front fender bracket	-	-	x	1.00 {0.039}
11	Lower arm bracket	-	-	x	2.30 {0.091}
12	Front frame rear	-	x	x	1.40 {0.055}
13	Front frame rear (upper)	-	x	x	1.40 {0.055}
14	Wheel apron panel	-	-	x	0.90 {0.035}
15	Torque box	-	-	x	1.20 {0.047}
16	Front frame reinforcement (outer)	-	x	x	1.40 {0.055}
17	Front frame reinforcement (upper)	x	-	x	1.80 {0.071}
18	Front frame reinforcement (inner)	-	x	x	1.40 {0.055}
19	Dash lower panel	-	-	x	0.75 {0.030}
20	Cowl upper plate	-	x	x	1.00 {0.039}
21	Dash upper panel	-	-	x	0.65 {0.026}
22	Cowl panel	-	-	x	0.65 {0.026}
23	Front pillar (inner)	-	x	-	2.00 {0.079}
		x	-	-	2.00 {0.079}
24	Side sill reinforcement (front)	x	-	x	1.60 {0.063}
25	Front pillar reinforcement	-	x	-	2.00 {0.079}
26	Hinge pillar (outer)	-	x	x	1.40 {0.055}
27	Cowl side panel	-	x	x	1.20 {0.047}
28	Cowl side reinforcement	-	x	x	1.00 {0.039}
29	Side sill reinforcement	-	x	x	1.80 {0.071}
30	Side sill (inner)	x	-	-	2.00 {0.079}
31	Side sill reinforcement (upper)	x	-	x	1.20 {0.047}
32	Rear fender panel	-	-	x	0.80 {0.031}
33	Side sill gusset	-	x	-	1.80 {0.071}
34	Center pillar (inner)	-	-	-	1.20 {0.047}
35	Wheel house (inner)	-	-	x	0.70 {0.028}
36	Side brace	-	-	-	0.70 {0.028}
		-	-	-	0.80 {0.031}
37	Striker reinforcement	-	-	-	1.40 {0.055}
38	End plate	-	-	-	0.70 {0.028}
39	Rear pillar (inner)	-	-	-	0.65 {0.026}
40	Package gusset	-	-	-	0.80 {0.031}
		-	-	-	1.00 {0.039}
41	Rear fender rain rail	-	-	x	0.90 {0.035}
42	Corner plate	-	-	x	0.80 {0.031}
43	Front header (upper)	-	-	x	1.00 {0.039}
44	Header reinforcement	-	-	-	1.40 {0.055}
45	Package tray	-	-	-	0.80 {0.031}
		-	-	-	1.00 {0.039}

BODY STRUCTURE [CONSTRUCTION]

No.	Part Name		Ultra high-tension steel	High-tension steel	Rust proof steel	Thickness (mm) {in}
46	Rear deck panel		-	-	x	0.80 {0.031}
47	Rear deck		-	-	-	0.70 {0.028}
48	Trunk lid panel	Convertible Top*	-	-	-	0.95 {0.037}
		Power Retractable Hardtop	-	x	x	0.65 {0.026}
49	Floor reinforcement		x	-	-	1.00 {0.039}
50	Front B frame		x	-	x	1.60 {0.063}
51	Member bracket		-	x	x	0.80 {0.031}
52	Front floor pan		-	-	x	0.65 {0.026}
53	Crossmember No.2		-	-	-	1.40 {0.055}
54	Rear side frame		-	x	x	1.20 {0.047}
55	Rear side frame		x	-	x	1.40 {0.055}
56	Center floor pan		-	x	x	0.80 {0.031}
57	Rear bumper bracket		-	x	x	1.20 {0.047}
58	Rear floor pan		-	-	x	0.65 {0.026}
59	Rear end member		-	-	-	0.65 {0.026}
60	Rear end panel		-	-	x	0.60 {0.024}
61	Door panel		-	x	x	0.65 {0.026}

(*) : Material is aluminum.

BODY STRUCTURE [CONSTRUCTION]

ADOPTION OF ULTRA HIGH-TENSION STEEL[CONSTRUCTION]

id098007785600


09-80A

Characteristics of Ultra High-Tensile Steel Plates

- Ultra high-tensile steel plates have enhanced tensile strength compared to previous high-tensile steel plates.
- Because the strength is maintained even though the plates are thin-walled, the ultra high-tensile steel plates are used for the frames and the main frame parts which form the cabin, reducing the weight of the vehicle.
- Enhanced shock absorption has improved the safety.

Range of Use and Cautions for Service

- Because the ultra high-tensile steel is hard and it may be difficult to reform, when extracting the damaged part using a frame repair machine, perform the work verifying that other parts are not affected.
- When drilling welded parts, use a well-ground drill bit.
- After welding, inspect the weld strength. If adhesion is poor, perform CO2 arc welding (plug welding).



D5U0980B031

*1 : Indicates tensile strength of 590 MPa.

*2 : Indicates tensile strength of 780 MPa.

09-80B BODY STRUCTURE [PANEL REPLACEMENT]

SHROUD UPPER PANEL REMOVAL
[PANEL REPLACEMENT] 09-80B-3

SHROUD UPPER PANEL INSTALLATION
[PANEL REPLACEMENT] 09-80B-4

SHROUD LOWER PANEL REMOVAL
[PANEL REPLACEMENT] 09-80B-5

SHROUD LOWER PANEL INSTALLTION
[PANEL REPLACEMENT] 09-80B-6

FRONT BUMPER BRACKET
INSTALLATION[PANEL
REPLACEMENT] 09-80B-7

FRONT BUMPER BRACKET REMOVAL
[PANEL REPLACEMENT] 09-80B-8

CROSSMEMBER No.1 REMOVAL
[PANEL REPLACEMENT] 09-80B-8

CROSSMEMBER No.1 INSTALLATION
[PANEL REPLACEMENT] 09-80B-11

COWL SIDE REINFORCEMENT
REMOVAL[PANEL
REPLACEMENT] 09-80B-13

COWL SIDE REINFORCEMENT
INSTALLATION[PANEL
REPLACEMENT] 09-80B-14

APRON REINFORCEMENT
OMPONENT REMOVAL
[PANEL REPLACEMENT] 09-80B-15

APRON REINFORCEMENT
COMPONENT INSTALLATION
[PANEL REPLACEMENT] 09-80B-16

APRON REINFORCEMENT (LOWER)
REMOVAL[PANEL
REPLACEMENT] 09-80B-17

APRON REINFORCEMENT (LOWER)
INSTALLATION[PANEL
REPLACEMENT] 09-80B-18

FRONT SIDE FRAME REAR
REINFORCEMENT REMOVAL
[PANEL REPLACEMENT] 09-80B-19

FRONT SIDE FRAME REAR
REINFORCEMENT INSTALLATION
[PANEL REPLACEMENT] 09-80B-20

FRONT SIDE FRAME (OUTER)
REMOVAL[PANEL
REPLACEMENT] 09-80B-21

FRONT SIDE FRAME (OUTER)
INSTALLATION[PANEL
REPLACEMENT] 09-80B-22

FRONT SIDE FRAME COMPONENT
REMOVAL[PANEL
REPLACEMENT] 09-80B-23

FRONT SIDE FRAME COMPONENT
INSTALLATION[PANEL
REPLACEMENT] 09-80B-24

FRONT SIDE FRAME
(PARTIAL CUTTING) REMOVAL
[PANEL REPLACEMENT] 09-80B-25

FRONT SIDE FRAME
(PARTIAL CUTTING) INSTALLATION
[PANEL REPLACEMENT] 09-80B-26

FRONT FRAME COMPONENT
(FRONT) REMOVAL[PANEL
REPLACEMENT] 09-80B-28

FRONT FRAME COMPONENT
(FRONT) INSTALLATION[PANEL
REPLACEMENT] 09-80B-30

FRONT FRAME COMPONENT
REMOVAL[PANEL
REPLACEMENT] 09-80B-32

FRONT FRAME COMPONENT
INSTALLATION[PANEL
REPLACEMENT] 09-80B-34

TORQUE BOX COMPONENT
REMOVAL[PANEL
REPLACEMENT] 09-80B-36

TORQUE BOX COMPONENT
INSTALLATION[PANEL
REPLACEMENT] 09-80B-38

FRONT PILLAR (OUTER) REMOVAL
[PANEL REPLACEMENT] 09-80B-40

FRONT PILLAR (OUTER)
INSTALLATION[PANEL
REPLACEMENT] 09-80B-41

HINGE PILLAR (OUTER) REMOVAL
[PANEL REPLACEMENT] 09-80B-43

HINGE PILLAR (OUTER)
INSTALLATION[PANEL
REPLACEMENT] 09-80B-47

REAR FENDER PANEL (LOWER)
REMOVAL[PANEL
REPLACEMENT] 09-80B-51

REAR FENDER PANEL (LOWER)
INSTALLATION[PANEL
REPLACEMENT] 09-80B-52

REAR FENDER PANEL REMOVAL
[PANEL REPLACEMENT] 09-80B-53

Convertible Top 09-80B-54

Power Retractable Hardtop 09-80B-55

REAR FENDER PANEL INSTALLATION
[PANEL REPLACEMENT] 09-80B-56

Convertible Top 09-80B-57

Power Retractable Hardtop 09-80B-57

SIDE SILL REINFORCEMENT
(FRONT) REMOVAL[PANEL
REPLACEMENT] 09-80B-59

SIDE SILL REINFORCEMENT (FRONT)
INSTALLATION[PANEL
REPLACEMENT] 09-80B-60

SIDE SILL REINFORCEMENT
(CENTER) REMOVAL[PANEL
REPLACEMENT] 09-80B-61

SIDE SILL REINFORCEMENT
(CENTER) INSTALLATION[PANEL
REPLACEMENT] 09-80B-62

SIDE SILL REINFORCEMENT
REMOVAL[PANEL
REPLACEMENT] 09-80B-63

SIDE SILL REINFORCEMENT
INSTALLATION[PANEL
REPLACEMENT] 09-80B-64

REAR END PANEL REMOVAL
[PANEL REPLACEMENT] 09-80B-65

REAR END PANEL INSTALLATION
[PANEL REPLACEMENT] 09-80B-65

09-80B

BODY STRUCTURE [PANEL REPLACEMENT]


CORNER PLATE REMOVAL		END PLATE REMOVAL	
[PANEL REPLACEMENT]	09-80B-66	[PANEL REPLACEMENT]	09-80B-77
CORNER PLATE INSTALLATION		END PLATE INSTALLATION	
[PANEL REPLACEMENT]	09-80B-66	[PANEL REPLACEMENT]	09-80B-78
REAR FENDER RAIN RAIL		CORNER JUNCTION REMOVAL	
(PARTIAL CUTTING) REMOVAL		[PANEL REPLACEMENT]	09-80B-80
[PANEL REPLACEMENT]	09-80B-67	CORNER JUNCTION INSTALLATION	
REAR FENDER RAIN RAIL		[PANEL REPLACEMENT]	09-80B-81
(PARTIAL CUTTING) INSTALLATION		WHEEL HOUSE (INNER) REMOVAL	
[PANEL REPLACEMENT]	09-80B-68	[PANEL REPLACEMENT]	09-80B-82
REAR DECK PANEL REMOVAL		WHEEL HOUSE (INNER)	
[PANEL REPLACEMENT]	09-80B-69	INSTALLATION[PANEL	
Convertible Top	09-80B-69	REPLACEMENT]	09-80B-83
Power Retractable Hardtop	09-80B-70	REAR FLOOR PAN REMOVAL	
REAR DECK PANEL INSTALLATION		[PANEL REPLACEMENT]	09-80B-84
[PANEL REPLACEMENT]	09-80B-71	REAR FLOOR PAN INSTALLATION	
Convertible Top	09-80B-71	[PANEL REPLACEMENT]	09-80B-86
Power Retractable Hardtop	09-80B-72	REAR SIDE FRAME	
REAR FENDER RAIN RAIL REMOVAL		(PARTIAL CUTTING) REMOVAL	
[PANEL REPLACEMENT]	09-80B-73	[PANEL REPLACEMENT]	09-80B-88
Convertible Top	09-80B-73	REAR SIDE FRAME	
Power Retractable Hardtop	09-80B-74	(PARTIAL CUTTING) INSTALLATION	
REAR FENDER RAIN RAIL		[PANEL REPLACEMENT]	09-80B-88
INSTALLATION[PANEL		FRONT HEADER REMOVAL	
REPLACEMENT]	09-80B-75	[PANEL REPLACEMENT]	09-80B-90
Convertible Top	09-80B-75	FRONT HEADER INSTALLATION	
Power Retractable Hardtop	09-80B-76	[PANEL REPLACEMENT]	09-80B-91

BODY STRUCTURE [PANEL REPLACEMENT]

SHROUD UPPER PANEL REMOVAL[PANEL REPLACEMENT]

id098008800400

1. Remove the shroud upper panel.



09-80B


D5U0980B040

BODY STRUCTURE [PANEL REPLACEMENT]

SHROUD UPPER PANEL INSTALLATION[PANEL REPLACEMENT]

id098008603000

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



D5U0980B041

BODY STRUCTURE [PANEL REPLACEMENT]


SHROUD LOWER PANEL REMOVAL[PANEL REPLACEMENT]

id098008603100

1. Remove the shroud lower panel.

Note

- When removing the hood lock bracket and the condenser bracket separately, drill the 7 locations indicated by (A) and the 6 locations indicated by (B).



D5U0980B042

09-80B

BODY STRUCTURE [PANEL REPLACEMENT]


SHROUD LOWER PANEL INSTALLTION[PANEL REPLACEMENT]

id098008603200

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.

Note

- When replacing the hood lock bracket and the condenser bracket separately, weld the 7 locations indicated by (A) and the 6 locations indicated by (B).




D5U0980B043

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT BUMPER BRACKET INSTALLATION [PANEL REPLACEMENT]

id098008743200

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



09-80B


D5U0980B045

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT BUMPER BRACKET REMOVAL[PANEL REPLACEMENT]

id098008743100

1. Remove the front bumper bracket.



D5U0980B044


CROSSMEMBER No.1 REMOVAL[PANEL REPLACEMENT]

id098008603500

1. Remove the crossmember No.1.

BODY STRUCTURE [PANEL REPLACEMENT]


09-80B



D5U0980B046

BODY STRUCTURE [PANEL REPLACEMENT]

2. Remove the crossmember No.1 side bracket.



D5U0980B052


BODY STRUCTURE [PANEL REPLACEMENT]

CROSSMEMBER No.1 INSTALLATION[PANEL REPLACEMENT]

id098008603600

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.
4. Install the crossmember No.1 side bracket.


09-80B



D5U0980B053

BODY STRUCTURE [PANEL REPLACEMENT]

5. Install the crossmember No.1.



D5U0980B047

BODY STRUCTURE [PANEL REPLACEMENT]


COWL SIDE REINFORCEMENT REMOVAL [PANEL REPLACEMENT]

id098008741700

1. Remove the cowl side reinforcement.

Caution

- Be careful not to damage the windshield when drilling the 2 locations indicated by (A).



09-80B


D5U0980B048

BODY STRUCTURE [PANEL REPLACEMENT]

COWL SIDE REINFORCEMENT INSTALLATION[PANEL REPLACEMENT]

id098008741800

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



D5U0980B049

BODY STRUCTURE [PANEL REPLACEMENT]


APRON REINFORCEMENT COMPONENT REMOVAL [PANEL REPLACEMENT]

id098008604700

1. Drill the 15 locations indicated by (A) and 13 locations indicated by (B), then remove the apron reinforcement component.

Note

- When removing the apron reinforcement (upper) separately, drill the 13 locations indicated by (B) and the 9 locations indicated by (C).



09-80B


D5U0980B050

BODY STRUCTURE [PANEL REPLACEMENT]

APRON REINFORCEMENT COMPONENT INSTALLATION[PANEL REPLACEMENT]

id098008604800

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.




D5U0980B051

BODY STRUCTURE [PANEL REPLACEMENT]

APRON REINFORCEMENT (LOWER) REMOVAL [PANEL REPLACEMENT]

id098008741300

1. Remove the apron reinforcement (lower).



09-80B


D5U0980B054

BODY STRUCTURE [PANEL REPLACEMENT]

APRON REINFORCEMENT (LOWER) INSTALLATION [PANEL REPLACEMENT]

id098008741400

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.




D5U0980B055

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT SIDE FRAME REAR REINFORCEMENT REMOVAL [PANEL REPLACEMENT]

id098008606500

1. Remove the front side frame rear reinforcement.



09-80B


D5U0980B056

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT SIDE FRAME REAR REINFORCEMENT INSTALLATION [PANEL REPLACEMENT]

id098008606600

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.




D5U0980B057

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT SIDE FRAME (OUTER) REMOVAL [PANEL REPLACEMENT]

id098008606100

1. Remove the front side frame (outer).



09-80B


D5U0980B058

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT SIDE FRAME (OUTER) INSTALLATION [PANEL REPLACEMENT]

id098008606200

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.




D5U0980B059

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT SIDE FRAME COMPONENT REMOVAL [PANEL REPLACEMENT]

id098008741900

1. Remove the front side frame component.



09-80B


D5U0980B060

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT SIDE FRAME COMPONENT INSTALLATION[PANEL REPLACEMENT]

id098008742000

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



D5U0980B061


BODY STRUCTURE [PANEL REPLACEMENT]

FRONT SIDE FRAME (PARTIAL CUTTING) REMOVAL [PANEL REPLACEMENT]

id098008742100

1. Rough cut and remove the damaged part of the front side frame.

09-80B



D5U0980B068

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT SIDE FRAME (PARTIAL CUTTING) INSTALLATION[PANEL REPLACEMENT]

id098008742200

Caution

- **The cut-and-joint area indicates the maximum size range of the installation position.**

1. Make a reinforcement panel using the material from the front side frame.
2. To cut and join the new and existing parts, cut the new part at the specified location shown in the figure, and chamfer the joint surfaces of the new and existing parts.
3. When installing the new parts, trial-fit new and existing parts, and then measure and adjust the body to conform with standard dimensions.
4. After temporarily installing new parts, make sure the related parts fit properly.


BODY STRUCTURE [PANEL REPLACEMENT]

5. Trial-fit the new and existing parts, weld the existing parts and the reinforcement, and then butt weld the new and existing parts.

Caution

- Press fit the reinforcement panel and the body side material, and then plug weld them.

09-80B



D5U0980B069

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT FRAME COMPONENT (FRONT) REMOVAL [PANEL REPLACEMENT]


id098008606300

1. Drill the 2 locations indicated by (A).

Note


- To prevent damage to the front side frame rear reinforcement, grind it using a belt grinder from the front side.

2. Remove the front frame component (front).



D5U0980B140

BODY STRUCTURE [PANEL REPLACEMENT]



09-80B

D5U0980B141

BODY STRUCTURE [PANEL REPLACEMENT]


FRONT FRAME COMPONENT (FRONT) INSTALLATION [PANEL REPLACEMENT]

id098008606400

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.


Caution

- Plug weld the 2 weld locations indicated by (A) together with the front side frame rear reinforcement.



D5U0980B142

BODY STRUCTURE [PANEL REPLACEMENT]



09-80B


D5U0980B143

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT FRAME COMPONENT REMOVAL [PANEL REPLACEMENT]

id098008616400



1. Drill the 2 location indicated by (A) from the interior, as they cannot be seen from the outer side.
2. Remove the front frame component.



D5U0980B062

BODY STRUCTURE [PANEL REPLACEMENT]

09-80B




D5U0980B063

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT FRAME COMPONENT INSTALLATION[PANEL REPLACEMENT]

id098008616500



1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



D5U0980B064

BODY STRUCTURE [PANEL REPLACEMENT]

09-80B



D5U0980B065

BODY STRUCTURE [PANEL REPLACEMENT]


TORQUE BOX COMPONENT REMOVAL [PANEL REPLACEMENT]

id098008616800

1. Remove the torque box component.

Note



- When removing the torque box separately, drill the 24 locations indicated by (A).



D5U0980B066

BODY STRUCTURE [PANEL REPLACEMENT]

09-80B




D5U0980B067

BODY STRUCTURE [PANEL REPLACEMENT]

TORQUE BOX COMPONENT INSTALLATION[PANEL REPLACEMENT]

id098008616900


1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.




D5U0980B070

BODY STRUCTURE [PANEL REPLACEMENT]

09-80B



TORQUE BOX COMPONENT



D5U0980B071

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT PILLAR (OUTER) REMOVAL [PANEL REPLACEMENT]


id098008716600

1. Rough cut area (A), drill the 18 locations indicated by (B).

Caution

- During rough cutting, be careful not to damage the front pillar reinforcement indicated by dotted lines in the figure.

2. Remove the bolt locations indicated by (C).
3. To facilitate removal of the front header, drill the 3 locations indicated by (D), then lift the cowl panel upward.
4. Remove the front header.
5. Remove the weld bond using a disc grinder.




D5U0980B072

BODY STRUCTURE [PANEL REPLACEMENT]

FRONT PILLAR (OUTER) INSTALLATION[PANEL REPLACEMENT]

id098008716700

1. To prepare for installation, cut area (A) on the new front header.
2. Grind the area (A) on the new front header with a disk grinder to finish the surface.



09-80B

D5U0980B119


3. When joining and cutting the new and existing parts, trial fit the new part in position, then measure and adjust the body as necessary to conform with standard dimensions.
4. Drill holes for plug welds before installing new parts.
5. After temporarily installing new parts, make sure the related parts fit properly.
6. Install the bolt locations indicated by (B).

Tightening torque

6.9—11.8 N·m {71—120 kgf·cm, 62—104 in·lbf}

7. Install the front header.

BODY STRUCTURE [PANEL REPLACEMENT]



D5U0980B073


BODY STRUCTURE [PANEL REPLACEMENT]

HINGE PILLAR (OUTER) REMOVAL [PANEL REPLACEMENT]

id098008613500

1. Drill the 2 locations indicated by (A) from the interior.
2. Remove the hinge pillar (outer).
3. Remove the spot weld sealer using a disc grinder.

09-80B




D5U0980B074

4. Remove the cowl side panel.

09-80B-43

BODY STRUCTURE [PANEL REPLACEMENT]


5. Remove the spot weld sealer using a disc grinder.



D5U0980B075

BODY STRUCTURE [PANEL REPLACEMENT]

6. Remove the front pillar reinforcement.




09-80B

D5U0980B076

BODY STRUCTURE [PANEL REPLACEMENT]

7. Remove the front pillar (inner).




D5U0980B077

BODY STRUCTURE [PANEL REPLACEMENT]

HINGE PILLAR (OUTER) INSTALLATION [PANEL REPLACEMENT]

id098008613600

1. When joining and cutting the new and existing parts, trial fit the new part in position, then measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.
4. Install the front pillar (inner).




D5U0980B078

09-80B

BODY STRUCTURE [PANEL REPLACEMENT]


5. Install the front pillar reinforcement.



D5U0980B079

6. Install the cowl side panel.

BODY STRUCTURE [PANEL REPLACEMENT]




09-80B

D5U0980B080

BODY STRUCTURE [PANEL REPLACEMENT]

7. Install the hinge pillar (outer).




D5U0980B081

BODY STRUCTURE [PANEL REPLACEMENT]

REAR FENDER PANEL (LOWER) REMOVAL [PANEL REPLACEMENT]

id098008614300

1. Remove the rear fender panel (lower).



09-80B


D5U0980B083

BODY STRUCTURE [PANEL REPLACEMENT]

REAR FENDER PANEL (LOWER) INSTALLATION [PANEL REPLACEMENT]

id098008614400

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



D5U0980B084

BODY STRUCTURE [PANEL REPLACEMENT]

REAR FENDER PANEL REMOVAL [PANEL REPLACEMENT]


id098008744900

1. Drill the 65 locations (vehicle with convertible top)/64 locations (vehicle with power retractable hardtop) indicated by (A), 17 locations indicated by (B), and 2 locations (vehicle with convertible top only) indicated by (C), then remove the rear fender panel.

Note

- Drilling of the 17 location indicated by (B) is not necessary when removing the rear fender panel and the side sill reinforcement (rear) at the same time.

09-80B



2. Remove the rear fender panel.

Note


- For weld the 2 location (C), partially bend back the rear deck panel before drilling.

09-80B-53

BODY STRUCTURE [PANEL REPLACEMENT]

3. Remove the spot weld sealer using a disc grinder.

Convertible Top




amxuub000000

BODY STRUCTURE [PANEL REPLACEMENT]

Power Retractable Hardtop

09-80B




amxuub0000004

BODY STRUCTURE [PANEL REPLACEMENT]

REAR FENDER PANEL INSTALLATION [PANEL REPLACEMENT]

id098008745000

1. When joining and cutting the new and existing parts, trial fit the new part in position, then measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. Before installing new parts, apply spot weld sealer to the wheel arch line.
4. After temporarily installing new parts, make sure the related parts fit properly.




amxuub000000

BODY STRUCTURE [PANEL REPLACEMENT]

Convertible Top

09-80B



amxuub000000

Power Retractable Hardtop

Note


- Spot weld the 3 locations indicated by (A) and assemble the rear fender and the corner plate before installing the rear fender to the vehicle.
- After assembling the rear fender and the corner plate, apply body sealer to the end of the panel mating surface to the area indicated by bold dotted lines in the figure.
- Drill holes for the plug welding before installing the new parts. The welding point of the location indicated by (B) is the same as the beginning of the plug weld on the 11 locations indicated by (C).

Caution

- Adjust the corner plate and rear fender so that the gap is 0.8 mm{0.031 in} or less to prevent water penetration.
- Apply body sealer to all areas of the corner plate assembly using a spatula.

09-80B-57

BODY STRUCTURE [PANEL REPLACEMENT]



amxuub0000007

BODY STRUCTURE [PANEL REPLACEMENT]

SIDE SILL REINFORCEMENT (FRONT) REMOVAL [PANEL REPLACEMENT]

id098008616200

1. Rough cut and remove the damaged part of the side sill reinforcement (front).


Caution

- During rough cutting, be careful not to damage the front pillar reinforcement indicated by dotted lines in the figure.

Note

- If the nut plate is not damaged, do not dispose of it, as it can be reinstalled. If it is damaged considerably, replace it with a new one.

09-80B




D5U0980B093

BODY STRUCTURE [PANEL REPLACEMENT]

SIDE SILL REINFORCEMENT (FRONT) INSTALLATION [PANEL REPLACEMENT]

id098008616300

1. When joining and cutting the new and existing parts, trial fit the new part in position, then measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.




D5U0980B094

BODY STRUCTURE [PANEL REPLACEMENT]

SIDE SILL REINFORCEMENT (CENTER) REMOVAL [PANEL REPLACEMENT]

id098008609600

1. Rough cut at the locations shown in the figure to remove damaged parts.
2. Remove the side sill reinforcement (center).



D5U0980B087


09-80B

BODY STRUCTURE [PANEL REPLACEMENT]

SIDE SILL REINFORCEMENT (CENTER) INSTALLATION [PANEL REPLACEMENT]

id098008609700

1. When joining and cutting the new and existing parts, trial fit the new part in position, then measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



D5U0980B088

BODY STRUCTURE [PANEL REPLACEMENT]


SIDE SILL REINFORCEMENT REMOVAL [PANEL REPLACEMENT]

id098008609200

Caution

- The side sill reinforcement removal procedure is based on the condition that the cowl side panel and the hinge pillar (outer) and the rear fender panel have been removed.

1. Remove the side sill reinforcement.



09-80B

D5U0980B089

BODY STRUCTURE [PANEL REPLACEMENT]


SIDE SILL REINFORCEMENT INSTALLATION[PANEL REPLACEMENT]

id098008609300

Caution

- The side sill reinforcement installation procedure is based on the condition that the cowl side panel and the hinge pillar (outer) and the rear fender panel have been removed.

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.




D5U0980B090

BODY STRUCTURE [PANEL REPLACEMENT]

REAR END PANEL REMOVAL [PANEL REPLACEMENT]

id098008744500

1. Remove the rear end panel.




D5U0980B095

09-80B

REAR END PANEL INSTALLATION [PANEL REPLACEMENT]

id098008744600

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.




D5U0980B096

BODY STRUCTURE [PANEL REPLACEMENT]

CORNER PLATE REMOVAL[PANEL REPLACEMENT]

id098008610400

1. Remove the corner plate.




D5U0980B109

CORNER PLATE INSTALLATION[PANEL REPLACEMENT]

id098008610500

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.




D5U0980B110

BODY STRUCTURE [PANEL REPLACEMENT]

REAR FENDER RAIN RAIL (PARTIAL CUTTING) REMOVAL [PANEL REPLACEMENT]

id098008610600

1. Rough cut at the locations shown in the figure to remove damaged parts.
2. Remove the rear fender rain rail and corner plate.



09-80B


D5U0980B097

BODY STRUCTURE [PANEL REPLACEMENT]

REAR FENDER RAIN RAIL (PARTIAL CUTTING) INSTALLATION [PANEL REPLACEMENT]

id098008610700

1. When joining and cutting the new and existing parts, trial fit the new part in position, then measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



amxuub0000000


BODY STRUCTURE [PANEL REPLACEMENT]

REAR DECK PANEL REMOVAL [PANEL REPLACEMENT]

id098008610800

1. Remove the rear deck panel.

Convertible Top




09-80B

amxuub000000

BODY STRUCTURE [PANEL REPLACEMENT]

Power Retractable Hardtop



amxuub00000010


BODY STRUCTURE [PANEL REPLACEMENT]

REAR DECK PANEL INSTALLATION [PANEL REPLACEMENT]

id098008610900

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.

Convertible Top




amxuub0000001

09-80B

BODY STRUCTURE [PANEL REPLACEMENT]

Power Retractable Hardtop



amxuub00000012


BODY STRUCTURE [PANEL REPLACEMENT]

REAR FENDER RAIN RAIL REMOVAL [PANEL REPLACEMENT]

id098008611000

1. Remove the rear fender rain rail.

Convertible Top




09-80B

amxuub0000001

BODY STRUCTURE [PANEL REPLACEMENT]

Power Retractable Hardtop



amxuub00000014


BODY STRUCTURE [PANEL REPLACEMENT]

REAR FENDER RAIN RAIL INSTALLATION [PANEL REPLACEMENT]

id098008611100

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.

Convertible Top




amxuub0000001

09-80B

BODY STRUCTURE [PANEL REPLACEMENT]

Power Retractable Hardtop




amxuub0000016

BODY STRUCTURE [PANEL REPLACEMENT]

END PLATE REMOVAL [PANEL REPLACEMENT]

id098008611200

1. Remove the bolt locations indicated by (A).
2. Remove the end plate.



09-80B

D5U0980B103

BODY STRUCTURE [PANEL REPLACEMENT]

END PLATE INSTALLATION[PANEL REPLACEMENT]

id098008611300

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.
4. Install the bolt locations indicated by (A).


Tightening torque

6.9—11.8 N·m {71—120 kgf·cm, 62—104 in·lbf}

5. Install the end plate.

BODY STRUCTURE [PANEL REPLACEMENT]

09-80B




D5U0980B104

BODY STRUCTURE [PANEL REPLACEMENT]

CORNER JUNCTION REMOVAL [PANEL REPLACEMENT]

id098008611400

1. Remove the corner junction.




D5U0980B105

BODY STRUCTURE [PANEL REPLACEMENT]

CORNER JUNCTION INSTALLATION [PANEL REPLACEMENT]

id098008611500

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



D5U0980B106


09-80B

BODY STRUCTURE [PANEL REPLACEMENT]

WHEEL HOUSE (INNER) REMOVAL [PANEL REPLACEMENT]

id098008611600

1. Remove the wheel house (inner).
2. Remove the spot weld sealer using a disc grinder.




D5U0980B107

BODY STRUCTURE [PANEL REPLACEMENT]

WHEEL HOUSE (INNER) INSTALLATION [PANEL REPLACEMENT]

id098008611700

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. Before installing new parts, apply spot weld sealer to the wheel arch line.
4. After temporarily installing new parts, make sure the related parts fit properly.



D5U0980B108

09-80B

BODY STRUCTURE [PANEL REPLACEMENT]

REAR FLOOR PAN REMOVAL [PANEL REPLACEMENT]


id098008742700

1. Rough cut area (A).

Caution

- During rough cutting, be careful not to damage the crossmember No.4 indicated by dotted lines in the figure.


2. Remove the rear floor pan.



D5U0980B111

BODY STRUCTURE [PANEL REPLACEMENT]

09-80B



D5U0980B112

BODY STRUCTURE [PANEL REPLACEMENT]

REAR FLOOR PAN INSTALLATION [PANEL REPLACEMENT]


id098008742800

1. When joining and cutting the new and existing parts, trial fit the new part in position, then measure and adjust the body as necessary to conform with standard dimensions.
2. Cut area (A) on the new part.
3. Drill holes for plug welds before installing new parts.
4. Apply spot sealer to the areas where both the overlapping ends of the new and existing parts will be welded. Adhere the sections to be welded, and fillet weld along both seams at the locations indicated by (B).

Note

- Create a flange with flanging tool where new and existing parts are joined.


5. Weld the remaining weld locations and install the rear floor pan.



D5U0980B113

BODY STRUCTURE [PANEL REPLACEMENT]

09-80B




D5U0980B114

BODY STRUCTURE [PANEL REPLACEMENT]

REAR SIDE FRAME (PARTIAL CUTTING) REMOVAL[PANEL REPLACEMENT]

id098008742900

1. Rough cut and remove the damaged part of the rear side frame.



D5U0980B115

REAR SIDE FRAME (PARTIAL CUTTING) INSTALLATION[PANEL REPLACEMENT]

id098008743000

Caution

- The cut-and-joint area indicates the maximum size range of the installation position.


1. Make a reinforcement panel using the material from the rear side frame.
2. To cut and join the new and existing parts, cut the new part at the specified location shown in the figure, and chamfer the joint surfaces of the new and existing parts.
3. When installing the new parts, trial-fit new and existing parts, and then measure and adjust the body to conform with standard dimensions.
4. After temporarily installing new parts, make sure the related parts fit properly.

BODY STRUCTURE [PANEL REPLACEMENT]

5. Trial-fit the new and existing parts, weld the existing parts and the reinforcement, and then butt weld the new and existing parts.

Caution

- Press fit the reinforcement panel and the body side material, and then plug weld them.



09-80B

D5U0980B116

BODY STRUCTURE [PANEL REPLACEMENT]


FRONT HEADER REMOVAL [PANEL REPLACEMENT]

id098008612700

1. Rough cut and remove the damaged part of the front header.

Caution

- During rough cutting, be careful not to damage the front pillar reinforcement indicated by dotted lines in the figure.




D5U0980B117

BODY STRUCTURE [PANEL REPLACEMENT]

id098008612800

FRONT HEADER INSTALLATION [PANEL REPLACEMENT]

1. When joining and cutting the new and existing parts, trial fit the new part in position, then measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for plug welds before installing new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.



09-80B

D5U0980B118

09-80C BODY STRUCTURE [WATER-PROOF AND RUST PREVENTIVE]

BODY SEALING[WATER-PROOF AND RUST PREVENTIVE] 09-80C-2
UNDER COATING[WATER-PROOF AND RUST PREVENTIVE] 09-80C-6

RUST PREVENTIVE TREATMENT [WATER-PROOF AND RUST PREVENTIVE]09-80C-7
DUMPING SHEET REPLACEMENT [WATER-PROOF AND RUST PREVENTIVE]09-80C-8


09-80C

BODY STRUCTURE [WATER-PROOF AND RUST PREVENTIVE]

BODY SEALING[WATER-PROOF AND RUST PREVENTIVE]


id098009739800

Sealant is applied to the parts where the panels meet and to the hemmed parts of the door panel and hood panel to provide water proofing and rust proofing.




D5U0980B120

BODY STRUCTURE [WATER-PROOF AND RUST PREVENTIVE]





09-80C



D5U0980B126

09-80C-3


BODY STRUCTURE [WATER-PROOF AND RUST PREVENTIVE]



D5U0980B121

BODY STRUCTURE [WATER-PROOF AND RUST PREVENTIVE]

09-80C




D5U0980B122

BODY STRUCTURE [WATER-PROOF AND RUST PREVENTIVE]

UNDER COATING[WATER-PROOF AND RUST PREVENTIVE]

id098009739900

The shaded areas indicated under body locations that are undercoated to prevent noise and rusting.




D5U0980B123

BODY STRUCTURE [WATER-PROOF AND RUST PREVENTIVE]

RUST PREVENTIVE TREATMENT[WATER-PROOF AND RUST PREVENTIVE]

id098009740100

09-80C





D5U0980B124

BODY STRUCTURE [WATER-PROOF AND RUST PREVENTIVE]

DUMPING SHEET REPLACEMENT[WATER-PROOF AND RUST PREVENTIVE]

id098009745700



D5U0980B125

09-80D BODY STRUCTURE [DIMENSIONS]

UNDERBODY FLAT-PLANE
DIMENSIONS [DIMENSIONS] 09-80D-2
UNDERBODY FRONT STRAIGHT-LINE
DIMENSIONS [DIMENSIONS] 09-80D-3
UNDERBODY REAR STRAIGHT-LINE
DIMENSIONS [DIMENSIONS] 09-80D-4
FRONT BODY STRAIGHT-LINE
DIMENSIONS (1) [DIMENSIONS] 09-80D-6
FRONT BODY STRAIGHT-LINE
DIMENSIONS (2) [DIMENSIONS] 09-80D-7
FRONT BODY STRAIGHT-LINE
DIMENSIONS (3) [DIMENSIONS] 09-80D-8

CABIN SIDE FRAME
STRAIGHT-LINE DIMENSIONS
[DIMENSIONS] 09-80D-9
ROOM STRAIGHT-LINE DIMENSIONS
(1) [DIMENSIONS] 09-80D-10
ROOM STRAIGHT-LINE DIMENSIONS
(2) [DIMENSIONS] 09-80D-11
ROOM STRAIGHT-LINE DIMENSIONS
(3) [DIMENSIONS] 09-80D-12
REAR BODY STRAIGHT-LINE
DIMENSIONS [DIMENSIONS] 09-80D-13


09-80D

BODY STRUCTURE [DIMENSIONS]

UNDERBODY FLAT-PLANE DIMENSIONS [DIMENSIONS]

id098010740400

- The following figures are bottom and side views.



D5U0980B001

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Front side frame datum hole	ø7 {0.28}
B	Crossmember No.1 datum hole	ø7 {0.28}
C	Engine mounting bolt	M14 {0.55}
D	Front suspension mounting block	ø64 {2.52}
E	Engine mounting bolt	M14 {0.55}
F	Front frame rear datum hole	ø16 {0.63}
G	Front frame rear datum slot	ø16 x 20 {0.63 x 0.79}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
H	Front B frame datum hole	ø12 {0.47}
I	Front B frame datum slot	ø12 x 18 {0.47 x 0.71}
J	Rear side frame datum hole	ø16 {0.63}
K	Rear crossmember mounting bolt	M14 {0.55}
L	Rear crossmember mounting bolt	M14 {0.55}
M	Rear suspension mounting block	ø97 {3.82}

BODY STRUCTURE [DIMENSIONS]


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
N	Rear crossmember mounting bolt	M14 {0.55}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
O	Rear side frame datum slot	ø16 x 20 {0.63 x 0.79}


UNDERBODY FRONT STRAIGHT-LINE DIMENSIONS [DIMENSIONS]

id098010748000

- The following figure is a bottom view.



D5U0980B020



D5U0980B021

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Front side frame datum hole	ø7 {0.28}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
B	Crossmember No.1 datum hole	ø7 {0.28}

09-80D

BODY STRUCTURE [DIMENSIONS]


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
C	Engine mounting bolt	M14 {0.55}
E	Engine mounting bolt	M14 {0.55}
F	Front frame rear datum hole	ø16 {0.63}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
G	Front frame rear datum slot	ø16 x 20 {0.63 x 0.79}
H	Front B frame datum hole	ø12 {0.47}

UNDERBODY REAR STRAIGHT-LINE DIMENSIONS [DIMENSIONS]


id098010748100

- The following figure is a bottom view.



D5U0980B022

BODY STRUCTURE [DIMENSIONS]



09-80D

D5U0980B023


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
H	Front B frame datum hole	∅12 {0.47}
I	Front B frame datum slot	∅12 x 18 {0.47 x 0.71}
J	Rear side frame datum hole	∅16 {0.63}
K	Rear crossmember mounting bolt	M14 {0.55}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
L	Rear crossmember mounting bolt	M14 {0.55}
N	Rear crossmember mounting bolt	M14 {0.55}
O	Rear side frame datum hole	∅16 x 20 {0.63 x 0.79}


BODY STRUCTURE [DIMENSIONS]

FRONT BODY STRAIGHT-LINE DIMENSIONS (1)[DIMENSIONS]

id098010740600



D5U0980B004



D5U0980B005


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Front header notch	-
B	Front header projection location	-
C	Front fender installation slot	ø10 x 12 {0.39 x 0.47}
D	Front combination light installation hole	ø7 {0.28}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
E	Front combination light installation hole	ø7 {0.28}
F	Front bumper reinforcement installation hole	ø14 {0.55}
G	Hood bracket datum hole	ø10 {0.39}
G'	Hood bracket datum slot	ø10 x 14 {0.39 x 0.55}

BODY STRUCTURE [DIMENSIONS]

FRONT BODY STRAIGHT-LINE DIMENSIONS (2)[DIMENSIONS]


id098010740700



mm {in}

09-80D

D5U0980B006



D5U0980B007


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Hood hinge installation hole	ø12 {0.47}
B	Front fender installation hole	ø7 {0.28}
C	Suspension housing upper datum hole	ø13 {0.51}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
D	Front fender installation hole	ø10 {0.39}
E	Front bumper installation hole	ø7 {0.28}


BODY STRUCTURE [DIMENSIONS]

FRONT BODY STRAIGHT-LINE DIMENSIONS (3)[DIMENSIONS]

id098010740800



D5U0980B008



D5U0980B009

BODY STRUCTURE [DIMENSIONS]


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Front header notch	-
B	Wiper installation hole	ø7 {0.28}
C	Hood hinge installation hole	ø12 {0.47}
D	Front fender installation hole	ø7 {0.28}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
E	Suspension mounting reinforcement datum hole	ø8.2 {0.32}
F	Front fender installation hole	ø10 {0.39}
G	Front side frame outer datum slot	ø10 x 14 {0.39 x 0.55}


CABIN SIDE FRAME STRAIGHT-LINE DIMENSIONS [DIMENSIONS]

id098010743600

09-80D



D5U0980B010



D5U0980B011


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Front side frame datum hole	ø20 {0.79}
B	Door hinge installation hole	ø12 {0.47}
C	Door hinge installation hole	ø12 {0.47}
D	Front header notch	-

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
E	Rear pillar notch	-
F	Door switch installation hole	ø7.2 {0.28}
G	Rear fender panel standard square hole	8 x 10 {0.31 x 0.39}


BODY STRUCTURE [DIMENSIONS]

ROOM STRAIGHT-LINE DIMENSIONS (1)[DIMENSIONS]

id098010743300



D5U0980B012



D5U0980B013


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Front haeder inner datum hole	ø7 {0.28}
B	Hinge pillar inner datum hole	ø7 {0.28}
C	Hinge pillar inner datum hole	ø5.4 {0.21}
D'	Console installation hole	ø3.8 {0.15}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
E	Side sill inner datum hole	ø7 {0.28}
F	Front header notch	-
G	Checker pin installation hole	ø10 {0.39}

BODY STRUCTURE [DIMENSIONS]


ROOM STRAIGHT-LINE DIMENSIONS (2)[DIMENSIONS]

id098010743400



09-80D

D5U0980B014



D5U0980B015


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Center pillar inner datum hole	ø14 {0.55}
B	Weather strip datum hole	ø5.2 {0.20}
C	Side sill inner rear datum hole	ø7 {0.28}
D'	Console installation hole	ø3.8 {0.15}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
E	Center floor pan datum hole	ø12 {0.47}
F	Side brace datum hole	ø7 {0.28}
G	Wheel house inner datum hole	ø10 {0.39}
H	Rear rein rail datum slot	ø12 x 7.2 {0.47x0.28}


BODY STRUCTURE [DIMENSIONS]

ROOM STRAIGHT-LINE DIMENSIONS (3)[DIMENSIONS]

id098010746200



D5U0980B016



D5U0980B017


Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Center pillar inner datum hole	ø14 {0.55}
B	Weather strip datum hole	ø5.2 {0.20}
C	Side sill inner rear datum hole	ø7 {0.28}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
D	Center floor pan datum hole	ø12 {0.47}
E	Wheel house inner datum hole	ø10 {0.39}
F	Rear rein rail datum slot	ø12 x 7.2 {0.47x0.28}

BODY STRUCTURE [DIMENSIONS]


REAR BODY STRAIGHT-LINE DIMENSIONS [DIMENSIONS]

id098010748200



09-80D

D5U0980B018



D5U0980B019

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
A	Corner plate standard slot	ø8 x 12 {0.31 x 0.47}
B	Rear fender standard hole	ø8 {0.31}
C	Corner plate standard hole	ø7 {0.28}

Point symbol	Designation	Hole diameter or bolt or nut size mm {in}
D	Rear end panel datum hole	ø12 {0.47}
D'	Rear end panel datum slot	ø12 x 6 {0.47 x 0.24}

BODY STRUCTURE [PLASTIC BODY PARTS]

09-80E BODY STRUCTURE [PLASTIC BODY PARTS]

PLASTIC PARTS HEAT RESISTING TEMPERATURE [PLASTIC BODY PARTS] 09-80E-1
REPAIRABLE RANGE OF POLYPROPYLENE BUMPERS [PLASTIC BODY PARTS] 09-80E-2

Repairable Bumpers **09-80E-2**
POLYPROPYLENE BUMPER REPAIR [PLASTIC BODY PARTS] 09-80E-3
PROCEDURE [PLASTIC BODY PARTS] 09-80E-4

PLASTIC PARTS HEAT RESISTING TEMPERATURE[PLASTIC BODY PARTS]

id098011740200

Part Name		Code	Material Name	Heat resisting Temperature°C{°F}
FRONT COMBINATION LIGHT	LENS	PC	POLYCARBONATE	130 {266}
	HOUSING	PP	POLYPROPYLENE	125 {257}
FRONT BUMPER		PP	POLYPROPYLENE	110 {230}
FRONT SIDE MARKER LIGHT	LENS	AS	AS	95 {203}
	HOUSING	ABS	ABS	88 {190}
OUTSIDE MIRROR	BASE	ABS	ABS	85 {185}
	BODY	ABS	ABS	85 {185}
	VISOR	AAS	AAS	88 {190}
SIDE STEP MOLDING		PP	POLYPROPYLENE	110 {230}
REAR BUMPER		PP	POLYPROPYLENE	110 {230}
REAR COMBINATION LIGHT	LENS	PMMA	ACRYLIC	95 {203}
	HOUSING	AES	AES	90 {194}
OUTER HANDLE	LEVER	PC-PBT	POLYCARBONATE-PBT	80 {176}
	BASE	PC-PET	POLYCARBONATE-PET	80 {176}
HIGH-MOUNT BRAKE LIGHT	LENS	PC	POLYCARBONATE	130 {266}
	HOUSING	PC	POLYCARBONATE	130 {266}
REFLECTOR	LENS	PMMA	ACRYLIC	90 {194}
	HOUSING	ABS	ABS	88 {190}
REAR DECK PLATE		ABS	ABS	100 {212}

09-80E

Note

- The application of temperatures higher than heat resisting temperatures may result in part deformation.

BODY STRUCTURE [PLASTIC BODY PARTS]


REPAIRABLE RANGE OF POLYPROPYLENE BUMPERS[PLASTIC BODY PARTS]

id098011600100

The three types of damaged bumpers shown below are considered repairable. Although a bumper which has been damaged greater than this could also be repaired, it should be replaced with a new one because such repair would detract from the looks and quality of the bumper. In addition, such repair is not considered reasonable in terms of work time.


Repairable Bumpers

1. A bumper with a hole less than 50 mm {1.97 in} in diameter.




YMU980PCM

2. A bumper with a crack less than 100 mm {3.94 in} in length.



YMU980PCN

3. A bumper with a crack less than 100 mm {3.94 in} in length that is less than half of the width of the bumper.




YMU980PCP

BODY STRUCTURE [PLASTIC BODY PARTS]

POLYPROPYLENE BUMPER REPAIR [PLASTIC BODY PARTS]

id098011600200

09-80E




YMU980PCQ

BODY STRUCTURE [PLASTIC BODY PARTS]

PROCEDURE[PLASTIC BODY PARTS]


id098011600300

Repair of polypropylene bumpers having damage that has reached the surface of the polypropylene and are too serious to be restored by painting only.



ZUA9818B001

1. Cut the rough edges around the damage with a knife to make it smooth. Sand the area with a sander to make an angle of about 45°.




ZUA9818B010

BODY STRUCTURE [PLASTIC BODY PARTS]


2. Weld the damaged area.

- For repair of a cracked area, melt the crack together with a heat gun and a melting attachment.



ZUA9818B003


- For repair of a hole, degrease the area on both sides of the bumper and apply aluminium tape on the reverse side of the damage area.



ZUA9818B005

09-80E


3. Melt the polypropylene welding rod with a heat gun and deposit it the cracked area.



ZUA9818B004

Note


- Heat the shaded area to melt it.
- Take care not to overly melt welding rod. If the part is welded with the welding rod melted like jelly, the welding strength will be reduced.
- Hold the heat gun 10—20 mm {0.39—0.79 in} from the part being welded.
- Do not move the welding rod until the welded parts cool.



ZUA9818B006


BODY STRUCTURE [PLASTIC BODY PARTS]

4. Sand the surface of the polypropylene gradually as it is easily melted by the abrasion heat. Sand the area to which repair agent will be applied.



YMU980PCX

5. Uniformly apply polypropylene primer with a brush to an area larger than the repaired area. Allow to dry about 10 minutes at 20 °C {68 °F}.




YMU980PCY

6. Mix the main agent and the stiffening agent in a ratio of one to one. Apply the mixed repair agent to the damaged area.

Note

- When mixing the main and stiffening agents, take care not to allow bubbles to form.
- The repair agent hardens quickly (about 5 minutes); proceed with the work immediately after mixing the agents.
- Allow about 30 minutes to dry (20 °C {68 °F}) before sanding.



YMU980PCZ

The repair agent is a two part epoxy adhesive.

When the repair agent hardens, it will provide a good finish with the same flexibility as the polypropylenes.


The repair agent for a **urethane** bumper is also a two part adhesive compound. However, this is different from that for a polypropylene bumper. If the incorrect repair agent is used, the repair will be faulty.

BODY STRUCTURE [PLASTIC BODY PARTS]

7. Sand the area with #180—240 sandpaper.

Note

- If excessive force is applied to the area when sanding, the surface will be damaged.
- If fuzz remains around the repaired area, melt it with a heat gun.




YMU980PD0

09-80E

8. Degrease the painted surface.

9. Mix the primer and the hardener at a ratio of one to one. Apply the primer to the repaired area and the surface of the bumper with a brush or spray.



YMU980PD1

Use the primer within 16 hours after it is mixed.


Note

- Polypropylene primer will dissolve even after drying if it is wiped with solvent. Use only water to clean around the primer.

10. Allow the part to dry.

BODY STRUCTURE [PLASTIC BODY PARTS]

11. Add the softener to the urethane primer surfacer and spray it on the repaired area.
 - a. Mixing method
Urethane primer surfacer + Softener Mixture A
Mixture A + hardener Mixture B
Dilute mixture B with thinner to spray on bumper
 - b. Viscosity
14—16 seconds/viscosimeter 20 °C {68 °F}



YMU980PD2

Note

- Mix the solutions at the specified ratio.

c. Spray pressure

300—400 kPa {3—4 kg/cm², 43—57 psi}

d. Standard film thickness

30—40 μ

e. Spray method

Spot-spray primer surfacer on bumper three or four times

12. Air drying 20 °C {68 °F} — 8 hours minimum.

Forced drying 60 °C {140 °F} — 1 hour

13. Lightly sand the complete surface of the bumper with #400—#600 sandpaper. Do not expose the surface of the polypropylene. (Wet or dry sanding is acceptable.)
14. Wipe the complete surface of the bumper with degreasing agent. Quickly wipe the surface with a clean rag to degrease it.
15. Apply a matching coat of body color to the polypropylene bumper.

Note

- Be sure to use only urethane primer for a urethane bumper and polypropylene primer for a polypropylene bumper. Other paints for repairing a polypropylene bumper are the same as those for the urethane bumper.

16. Air drying 20 °C {68 °F} — 8 hours minimum.

Forced drying 60 °C {140 °F} — 1 hour

Note

- Let the part air dry when possible as forced drying could cause bubbles in the top coat.